visual engineering
LIGHTWARE

User's Manual

MX16x16DVI-Slim
MX12x12DVI-Slim

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
SOURCES
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
DESTINATIONS
visual engineering
LIGHTWARE
16x16 DVI MATRIX ROUTER
MX16x16DVI-Slim

PRELIMINARY VERSION!

SAFETY INSTRUCTIONS

Class I apparatus construction. This equipment must be used with a main power system with a protective earth connection. The third (earth) pin is a safety feature, do not bypass or disable it.

This equipment should be operated only from the power source indicated on the product.

To disconnect the equipment safely from power, remove the power cord from the rear of the equipment, or from the power source. The MAINS plug is used as the disconnect device, the disconnect device shall remain readily operable.

There are no user-serviceable parts inside of the unit. Removal of the top cover will expose dangerous voltages. To avoid personal injury, do not remove the top cover. Do not operate the unit without the cover installed.

The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

The apparatus must be safely connected to multimedia systems. Follow instructions described in this manual.

Replacing the AC fuse

Unplug the AC power cord from the equipment

Locate the AC fuse on the rear of the unit

Replace only the AC fuse as indicated on the rear panel of the unit: 3.15A fast blowing

Connect the power cord to the switcher and to the AC power source. Make sure the switcher is working properly.

WEEE (Waste Electrical & Electronic Equipment)

Correct Disposal of This Product

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

PRELIMINARY VERSION!

CE

DECLARATION OF CONFORMITY

We,

Lightware Kft. 1071 Budapest Peterdy str. 15 HUNGARY

as manufacturer declare, that the products

MX16x16DVI-Slim
MX12x12DVI-Slim

(Computer Matrix Switcher)

in accordance with the EMC Directive 2004/108/EC and the Low Voltage Directive 2006/95/EEC are in conformity with the following standards:

EMI/EMC ..... EN 55103-1 E3, EN 55103-2

Safety ..... EN 60065 Class I

PRELIMINARY VERSION!

Date: 01 March 2008

Name: Gergely Vida (Managing Director)

Signed: Vida A. Gergely

Table of contents

1. INTRODUCTION 8

1.1. BOX CONTENTS 8
1.2. DESCRIPTION 8
1.3. FEATURES 9
1.4. APPLICATIONS 10
1.5. UNDERSTANDING EDID 11
1.5.1. Basics 11
1.5.2. Common problems related to EDID 11
1.6. ADVANCED EDID MANAGEMENT 12

2. CONTROLS AND CONNECTIONS 13

2.1. FRONT PANEL VIEW 13
2.2. REAR VIEW 14
2.3. POWER SUPPLY UNIT 15
2.4. ELECTRICAL CONNECTIONS 16
2.4.1. Power connector 16
2.4.2. DVI inputs 17
2.4.3. DVI outputs 18
2.4.4. RS-232 / RS-422 control port 19
2.4.5. Ethernet port 19

3. OPERATION 20

3.1. POWERING ON 20
3.2. FRONT PANEL OPERATIONS 20
3.2.1. CONTROL LOCK 20
3.2.2. TAKE / AUTOTAKE modes 21
3.2.3. Viewing crosspoint state 21
3.2.4. Switching 22
3.2.5. Switching operations flowchart 23
3.2.6. SAVE or LOAD PRESETS 24
3.2.7. OUTPUT LOCK 24
3.3. REMOTE OPERATION 26

4. SOFTWARE CONTROL – USING LIGHTWARE MATRIX CONTROLLER 27

4.1. INSTALLING THE MATRIX CONTROLLER SOFTWARE 27
4.2. ESTABLISHING THE CONNECTION 29
4.3. CONTROL MENU 31
4.3.1. Switch, mute and lock 31
4.3.2. Input and output card types 32
4.3.3. Input and output names 32
4.3.4. PRESET operations 32
4.3.1. Output parameter settings 34
4.4. EDID MENU 34
4.4.1. EDID Router operation 35
4.4.2. Advanced EDID Editor 37
4.5. TERMINAL MENU 38
4.6. STATUS MENU 38
4.6.1. IP settings 39
4.7. FIND MENU 40

5. WEB CONTROL – USING BUILT-IN WEBSITE 41

5.1. ACCESSING THE ROUTER'S BUILT-IN WEBSITE 41
5.2. MENU DESCRIPTION 42
5.3. CONTROL MENU 43
5.3.1. Crosspoint switching 43
5.3.2. Preset operations 43
5.3.3. Output settings 44

PRELIMINARY VERSION!

5.4. EDID ROUTER OPERATION 45
5.4.1. Change emulated EDID at one or all inputs 45
5.4.2. Learn EDID from attached display device 46
5.5. STATUS 46
5.6. NETWORK CONFIGURATION 47
5.6.1. Automatic IP Address Configuration 47
5.6.2. Static IP address configuration 47
5.6.3. Loading the default IP settings 48
5.6.4. TCP Port Configuration 48
5.6.5. Loading the default TCP Port settings 48
5.7. SUPPORT 48

6. ABOUT EDID MEMORY 49

7. PROGRAMMER'S REFERENCE 50

7.1. CHANGING AND VIEWING PROTOCOLS 50
7.2. SERIAL PORT SETTINGS 50
7.3. ETHERNET PORT SETTINGS 50
7.4. PROTOCOL DESCRIPTION 51
7.5. SWITCHING AND CONTROL COMMANDS 52
7.5.1. Switch one input to one output 52
7.5.2. Switch one input to all outputs 52
7.5.3. View connection on the specified output 52
7.5.4. View connection on all outputs 52
7.5.5. View mutes on all outputs 53
7.5.6. Mute specified output 53
7.5.7. Unmute specified output 54
7.5.8. Lock specified output 54
7.5.9. Unlock specified output 54
7.5.10. Save preset to the specified memory location 54
7.5.11. Load preset from the specified location 54
7.5.12. Preview preset 55
7.5.13. Renaming Presets / Inputs / Outputs 55
7.5.14. Query names of Presets / Inputs / Outputs 56
7.5.15. Set default names of Presets / Inputs / Outputs 56
7.5.16. Reload factory default output setup 57
7.5.17. Query IP settings 57
7.5.18. Reload factory default IP settings 57
7.5.19. Load DHCP IP settings (only IP address!) 58
7.6. ROUTER STATUS COMMANDS 59
7.6.1. View product type 59
7.6.2. View serial number 59
7.6.3. View Firmware version of the CPU 59
7.6.4. View Installed I/O cards' hardware 59
7.6.5. View installed controllers' firmware 60
7.6.6. View current control protocol 60
7.6.7. Set current control protocol 60
7.7. EDID ROUTER COMMANDS 61
7.7.1. Route EDID to the selected input (static) 61
7.7.2. Route EDID to the selected input (dynamic) 61
7.7.3. Route one EDID to all inputs 61
7.7.4. View EDID switch status on all inputs 61
7.7.5. Save EDID from output to memory location (Learn EDID) 62
7.7.6. View EDID validity table 62
7.7.7. View EDID header 63
7.7.8. Download EDID content from the router 63
7.7.9. Upload EDID content to the router 63
7.8. ROUTER INITIATED COMMANDS 64
7.8.1. EDID status changed 64
7.8.2. Error responses 65

PRELIMINARY VERSION!

7.9. COMMANDS – QUICK SUMMARY 66
8. FIRMWARE UPGRADE 67
9. TROUBLESHOOTING 71
9.1. SERIAL CONNECTION PROBLEMS 71
9.2. TCP/IP CONNECTION PROBLEMS 71
9.3. PICTURE IS NOT DISPLAYED OR DISTORTED 71
10. VERSION APPLICABILITY 72
11. SPECIFICATIONS 73
11.1. MECHANICAL DRAWINGS (ROUTER) 75
11.2. MECHANICAL DRAWINGS (POWER SUPPLY) 76
12. WARRANTY 77
13. QUALITY CHECK RECORD 78
14. REVISION HISTORY 79

PRELIMINARY VERSION!

1. Introduction

Thank you for choosing Lightware DVI matrix routers. The MX16x16DVI-Slim and MX12x12DVI-Slim router are able to switch 16 inputs to 16 outputs or 12 inputs to 12 outputs in a non-blocking crosspoint configuration respectively.

1.1. Box contents

- Routing switcher
- Power supply unit
- Speakon DC power cable
- IEC power cable
- User's manual (this document)
- CD-ROM with control software
- RS-232 9 pole D-SUB Male to Female cable
- UTP cross link cable

1.2. Description

Lightware MX16x16DVI-Slim and MX12x12DVI-Slim are single link DVI matrix switchers with 16 DVI inputs and 16 DVI outputs or 12 DVI inputs and 12 DVI outputs respectively, which routes any input(s) to any combination of output(s).

The router conforms to DVI 1.0 specification, and switches signals between 25 - 165 MHz pixel clock frequency: from 640x480@60Hz to 1920x1200@60Hz or 2048x1080@60Hz PC resolutions.

The input signals are compensated for 12dB loss and outputs are preemphasized by +6dB, this way cable lengths up to 20 meters (65 feets) can be used.

The switcher has an RS-232 (or RS-422 optional) and an RJ45 LAN port for remote control applications and a control panel for local control operation. Front panel buttons are illuminated and easily relegendable with text for informative system integration.

PRELIMINARY VERSION!

1.3. Features

- **Advanced EDID Management** – The user can emulate any EDID on the switcher's inputs independently, read out and store any attached monitor's EDID in 100 internal memory locations, upload and download EDID files using Matrix Control Software.
- **Non-blocking cross point matrix architecture** – The router allows any input to be switched to any output or more outputs simultaneously.
- **2.25 Gb/s channel transmission** – Routes any DVI single link signal between 25 and 165 MHz pixel clock frequency conforming to DVI 1.0 standard.
- **Supports all HDTV resolutions** – 720p, 1080i and 1080p etc. without HDCP encoding - Unencrypted HDTV signals up to 165 MHz pixel clock frequency regardless of resolution are passed through.
- **Cable equalization** – DVI cables up to 20 meters can be used on all inputs thanks to the +12dB compensation.
- **Output boost** – DVI cables up to 20 meters can be used on all outputs thanks to the +6dB preemphasizing circuit.
- **Front panel buttons control** – 16 or 12 source select, 16 or 12 destination select, Take, Load preset, Save preset, Control Lock, Output Lock
- **Relegendable buttons** – Each button has an easy removable flat cap and a translucent label which can be inserted under it to identify sources and destinations.
- **RS-232 or RS-422 control** – Simple ASCII based protocol is used for switching, preset calling, status request, etc.
- **Ethernet control** – TCP/IP Ethernet 10Base-T or 100Base TX (Auto-Sensing)
- **Built-in WEB site** – easy access from a WEB browser to control and configure the switcher
- **Fiber cable support** – Self powered DVI fiber cables using +5V from DVI sources (VGA cards, etc.) usually consume more than 50 mA, which load is maximum allowed by DVI 1.0 standard. Lightware routers support +5V 500 mA constant current output on each DVI output to power long distance fiber optical cables.
- **Universal power supply** – Accepting AC voltages from 100 to 240 Volts with 50 or 60 Hz line frequency on standard IEC connector.
- **Power failure memory** – In case of power failure the unit stores its latest configuration, and after next power up it loads automatically.
- **Ultra thin & light** – only 31.5 mm (1.2 inch) deep, 4U high rack mountable housing. Thanks to the aluminum alloy body, the matrix router weighs only 1.85 kg (4.1 lbs).

PRELIMINARY VERSION!

1.4. Applications

Some typical connection variations with the matrix router are shown on Figure 1-1.



Figure 1-1. Typical application

PRELIMINARY VERSION!

1.5. Understanding EDID

1.5.1. Basics

EDID stands for Extended Display Identification Data. Simply put, EDID is the passport of display devices (monitors, TV sets, projectors). It contains information about the display's capabilities, such as supported resolutions, refresh rates (these are called Detailed Timings), the type and manufacturer of the display device, etc.

After connecting a DVI source to a DVI display, the source reads out the EDID to determine the resolution and refresh rate of the image to be transmitted.



Figure 1-2. EDID communication

Most DVI computer displays have 128-byte long EDID structure. However, Digital Televisions and HDMI capable displays may have another 128 bytes, which is called E-EDID and defined by CEA (Consumer Electronics Association). This extension contains information about additional Detailed Timings, audio capabilities, speaker allocation and HDMI capabilities. It is important to know, that all HDMI capable devices must have CEA extension, but not all devices are HDMI capable which have the extension.

1.5.2. Common problems related to EDID

Problem: „My system consists of the following: a computer, a Lightware MX16x16DVI-Slim matrix, a WUXGA (1920x1200) LCD monitor, and a SXGA (1280x1024) projector. I would like to see the same image on the monitor and the projector. What EDID should I chose on the router?"

Solution: If you want to see the image on both displays, you need to select the resolution of the smaller display (in this case SXGA), otherwise the smaller display may not show the higher resolution image.

PRELIMINARY VERSION!

Problem: „I have changed to a different EDID on an input port of the matrix to have a different resolution but nothing happens."

Solution: Some graphics cards and video sources read out the EDID only after power-up and later they don't sense that EDID has been changed. You need to restart your source to make it read out the EDID again.

1.6. Advanced EDID Management

Each DVI sink (e.g. monitors, projectors, plasma displays, and switcher inputs) must support the EDID data structure. Source BIOS and operating systems are likely to query the sink using DDC2B protocol to determine what pixel formats and interface are supported. DVI standard makes use of EDID data structure for the identification of the monitor type and capabilities. Most DVI sources (VGA cards, set top boxes, etc) will output DVI signal after accepting the connected sink's EDID information. In case of EDID readout failure or missing EDID the source will not output DVI video signal.

MX16x16DVI-Slim and MX12x12DVI-Slim provide Lightware's Advanced EDID Management function that helps system integration. The built in EDID Router stores and emulates 100 EDID data plus all monitor's EDID that are connected to the output connectors. First 50 EDID are factory presets, while memories 51 to 100 are user programmable. The router stores the EDID of all attached monitors or projectors for each output in a non-volatile memory. This way the EDID from a monitor is available when the monitor is unplugged, or switched off.

Any EDID can be emulated on any input. An emulated EDID can be copied from the EDID router's memory (static EDID emulation), or from the last attached monitors memory (dynamic EDID emulation). For example, the router can be set up to emulate a device, which is connected to one of the outputs. In this case the EDID automatically changes, if the monitor is replaced with another display device (as long as it has a valid EDID).

EDID is independently programmable for all inputs without affecting each other. All input has it's own EDID circuit. EDID Router can be controlled via serial port or Ethernet.

Info *The user is not required to disconnect the DVI cable to change an EDID as opposed to other manufacturer's products. EDID can be changed even if source is connected to the input and powered ON.*

Info *When EDID has been changed, the router toggles the HOTPLUG signal for 2 seconds. Some sources do not observe this signal, so in this case the change is not recognized by the source. In such cases the source device must be restarted or powered OFF and ON again.*

PRELIMINARY VERSION!

2. Controls and connections

2.1. Front panel view



Figure 2-1. Front panel view

1	**Control Lock**	Disables or enables front panel operation. When red illuminated, all operations on front panel are prohibited. *See section **3.2.1** on page 20 for more information.*
2	**Output Lock**	Locks and protects one (or more) outputs. Inhibits accidental input changing on protected output. *See section **3.2.7** on page 24 for more information.*
3	**Source buttons**	Source buttons have three functions: to select an input, to select a preset and to view the selected input's state (only in TAKE mode). *See section **3.2.3** on page 21 for more information.*
4	**Destination buttons**	Destination buttons have two functions: to select an output, or to view the selected output's state. *See section **3.2.4** on page 22 for more information.*
5	**Take / Auto**	Displays the actual switching mode of the router (TAKE or AUTOTAKE). Long press toggles the switching mode, short press executes switching in TAKE mode. *See section **3.2.2** on page 21 for more information.*
6	**Load Preset**	Loads and executes a previously saved preset from one of the preset memories. *See section **3.2.6** on page 24 for more information.*
	Save Preset	Stores actual matrix state, in one of the preset memories. *See section **3.2.6** on page 24 for more information.*

Info *MX12x12DVI-Slim front panel differs only in that it has only 12 source and 12 destination buttons.*

PRELIMINARY VERSION!

2.2. Rear view



Figure 2-2. Rear view

1	**DC voltage indicators**	LED indicators for internal DC power voltages.
2	**DC power connector**	Speakon 4 pole receptacle. Connect ONLY to matching power supply (MX-PSU-125) supported by Lightware. See section ***2.4.1*** for more information.
3	**Serial port**	9 pole D-SUB female connector. Can be ordered with RS-232 or RS-422 control.
4	**Ethernet port**	RJ45 connector. Remote control port for connecting the unit to Local Area Network (LAN).
5	**Input connectors**	29 pole DVI–I digital-only female receptacle connectors. Connect DVI source devices to these connectors.
6	**Output connectors**	29 pole DVI–I digital-only female receptacle connectors. Connect DVI sink devices to these connectors.
7	**CPU live LED**	Continuously blinking LED if the CPU works properly.
8	**Reset button**	Resets all internal hardware elements.

Info *MX12x12DVI-Slim rear panel differs only in that it has only 12 input and 12 output connectors.*

PRELIMINARY VERSION!

2.3. Power supply unit



Figure 2-3. Power supply

1 **Fan air inlet**	Low noise fan. Never block air flow!
2 **AC connector**	Standard IEC power connector. Works with 100 to 240 Volts, 50 or 60 Hz power sources.
3 **AC fuse**	Replace with F 3.15 A type only.
4 **Clamp**	Prevents the IEC plug from loosing, or slipping out.
5 **DC connector**	Speakon 4 pole connector. Connect to router with supported cable. See section 2.4.1 for more information.
6 **Power switch**	Power supply can be switched OFF/ON with this switch.

PRELIMINARY VERSION!

2.4. Electrical connections

2.4.1. Power connector

Neutrik Speakon locking connector is used to connect the power supply unit with the router. The connector is made with custom pin assignment. Using the DC power cable provided with the router is always recommended.

Warning: *Never use the cable of other electronic equipment that seems to be compatible with this connector!*

DC power connector pin assignment

If a custom length DC power cable has to be made, follow the below specification.

Recommended cable: 4 wire, each 4 mm^2 (4×AWG12)
Maximum length 1.5 meters (5 feet)

Current: 10 A @ 3.3 V DC
10 A @ 5 V DC

Cable connector type: *Neutrik Speakon **NL4FC***



Figure 2-4. DC power cable connector pin assignments

Chassis connector type: *Neutrik Speakon **NL4MP***



Figure 2-5 DC chassis connector pin assignments

PRELIMINARY VERSION!

2.4.2. DVI inputs

MX16x16DVI-Slim and MX12x12DVI-Slim provide 29 pole DVI-I connectors, however only digital pins are internally connected. This way, users can plug in any DVI connector, but keep in mind that no analog signals (such as VGA or RGBHV) are processed.

Always use high quality DVI cable for connecting sources and displays.

Fix +12 dB cable equalization is provided, this way DVI cables up to 20 meters can be used on all inputs.

Pin	Signal	Pin	Signal	Pin	Signal
1	TMDS Data2-	**9**	TMDS Data1-	**17**	TMDS Data0-
2	TMDS Data2+	**10**	TMDS Data1+	**18**	TMDS Data0+
3	TMDS Data2 Shield	**11**	TMDS Data1 Shield	**19**	TMDS Data0 Shield
4	*nc*	**12**	*nc*	**20**	*nc*
5	*nc*	**13**	*nc*	**21**	*nc*
6	DDC Clock	**14**	+5V Power	**22**	TMDS Clock Shield
7	DDC Data	**15**	GND (for +5V)	**23**	TMDS Clock+
8	nc	**16**	Hot Plug Detect	**24**	TMDS Clock-
C1	nc	**C2**	nc	**C3**	nc
C4	nc	**C5**	GND		

Table 2-1. DVI connector pin assignments



Figure 2-6. DVI-I connector

PRELIMINARY VERSION!

2.4.3. DVI outputs

MX16x16DVI-Slim and MX12x12DVI-Slim provide 29 pole DVI-I connectors for outputs, however only digital pins are internally connected. This way, users can plug in any DVI connector, but keep in mind that no analog signals (such as VGA or RGBHV) are processed.

Thanks to the fix +6 dB pre-emphasizing circuit, DVI cables up to 20 meters can be used. For using longer cable runs at outputs, use fiber optical DVI transmitters (like Lightware DVI-OPT-TX100) or active DVI repeaters/extenders.

No output reclocking is provided.

Fiber Cable powering

As special feature MX16x16DVI-Slim and MX12x12DVI-Slim are able to supply 500 mA current on DDC +5V output (pin 14 on output connectors) to power fiber optical DVI cables. Standard DVI outputs or VGA cards supply only 55 mA current on +5V output, thus unable to power directly a fiber optical cable.

Info *The matrix switcher does not check if the connected sink (monitor, projector or other equipment) supports Hotplug or EDID signals but outputs the selected signal immediately after switch command.*

PRELIMINARY VERSION!

2.4.4. RS-232 / RS-422 control port

Lightware MX16x16DVI-Slim and MX12x12DVI-Slim can be remote controlled through industry standard 9 pole D-SUB female connector located on the rear panel of the unit. The router can be ordered with RS-232 or RS-422 control port.



Figure 2-7. D-SUB 9 pole connector

Pin nr.	RS-232	RS-422
1	NC non connected	TX- data transmit complement
2	**TX data transmit**	TX+ data transmit true
3	**RX data receive**	RX+ data receive true
4	DTR internally connected to Pin 6	RX- data receive complement
5	**GND signal ground (shield)**	GND signal ground (shield)
6	DSR internally connected to Pin 4	NC non connected
7	RTS internally connected to Pin 8	NC non connected
8	CTS internally connected to Pin 7	NC non connected
9	NC non connected	NC non connected

Table 2-2. D-SUB 9 pole pin assignments

2.4.5. Ethernet port

The Ethernet port can be connected to a LAN hub, switch or router with a UTP path cable. If connecting to a computer directly, a cross UTP cable has to be used!

See section 3.3 about remote operation on page 26 for more information.



Pin nr.	Name	Wire color
1	TX +	Green stripe
2	TX -	Green
3	RX +	Orange stripe
4	Not used	Blue
5	Not used	Blue stripe
6	RX -	Orange
7	Not used	Brown stripe
8	Not used	Brown

Figure 2-8. RJ45 connector Table 2-3. Ethernet pin assignments

PRELIMINARY VERSION!

3. Operation

3.1. Powering on

Connect the power cord to the power supply unit's IEC standard AC power input connector. The unit can be switched ON/OFF with a switch on the front side. When it is on, the switch illuminates, and the fan operates.

Connect the router to the power supply with the supplied DC power cable. The router itself does not have a power switch, it remains powered on until the power supply unit is on.

After powered on, the unit performs a self test, and then all front panel buttons light up for one second. After the self test the CPU live LED starts blinking, the router reloads its last configuration and it is ready to use.

Info *At switching ON, the router reloads the latest settings which were used before it was turning off. The unit has an internal emergency memory which stores all current settings, and ties configurations. This memory is independent from presets and invisible for the user. This built-in feature helps the system to be ready immediately in case of power failure or accidentally powering down.*

3.2. Front panel operations

3.2.1. CONTROL LOCK

Front panel button operations can be enabled or disabled using CONTROL LOCK button, while RS-232 / RS-422 and Ethernet control is still enabled. If the button is not illuminated, front panel button operations are enabled. If it illuminates red continuously, front panel operations are inhibited.

Press and hold the CONTROL LOCK button for 3 seconds to toggle the control lock state.

PRELIMINARY VERSION!

3.2.2. TAKE / AUTOTAKE modes

The router has two different switching modes: TAKE and AUTOTAKE. If the TAKE / AUTO button is unlit, TAKE mode is active. When the TAKE / AUTO button continuously lights green, AUTOTAKE mode is selected.

Press and hold the TAKE button for three seconds to toggle between TAKE and AUTOTAKE modes.

TAKE mode allows the user to make multiple connections and disconnections at once. This mode is useful when time delay is not allowed between multiple switching. The commands are only realized when the TAKE button is pressed. If no button is pressed for two seconds, all preselected actions (which were not realized with the pressing TAKE) will be ignored, and the router returns to its idle state.

AUTOTAKE mode is useful when immediate actions must be done or fast switching is needed between sources on a particular destination. In this mode switching occurs immediately upon pressing one of the input selector buttons.

3.2.3. Viewing crosspoint state

User can check the current switching status on the front panel using front panel buttons. This status view feature is slightly different in TAKE or AUTOTAKE modes because of different switching philosophy of the two modes.

Info *Status view occurs whenever the router has to be switched. After entering the view state, the user can change the routing configuration. Viewing and switching can be done after each other, or if nothing is pressed for three seconds, the router returns to idle state.*

View current state in TAKE mode

If all source and destination buttons and TAKE button are unlit (the unit is in TAKE mode, and no input was selected in last 3 seconds), user can verify both input and output connections. This informative display will remain for 3 seconds, and then all button lamps go out. In TAKE mode no accidental change can be done unless TAKE button is pressed.

For viewing **input connections**, press and release a source button. Now the selected source button and all destination buttons will light up which are currently connected to the selected source.

For viewing **output connections**, press and release a destination button. Now the source button which is connected to the selected destination will light up. If no source button is lighting, the selected destination is in muted state.

View current state in AUTOTAKE mode

In AUTOTAKE mode only states of destinations can be viewed.

Press and release the required destination button. Now the source button which is connected to the selected destination will light up. If no source button is lighting, the selected destination is in muted state. By pressing another destination button, the state of that destination can be seen.

Info *Be careful, as in AUTOTAKE mode if a source button is pressed, it is immediately connected to the last selected destination.*

PRELIMINARY VERSION!

3.2.4. Switching

Creating a connection or multiple connections in TAKE mode

Step 1. First press and release the selected source button. The pressed source button and all destination buttons which are currently connected to this source will light up. The dark remaining destination buttons are not connected to this source. This is an informative display about current status of the selected input (view only).

Step 2. Press and release the selected destination button or buttons which has to be connected to the selected source. The preselected destination button(s) start(s) blinking.

Step 3. Press and release TAKE button to execute the tie or ties. Now the selected input is switched to the selected output or to the multiple outputs.

Disconnecting or muting in TAKE mode

Step 1. First press and release the selected source button. The pressed source button and all destination buttons which are currently connected to this source will light up. The dark remaining destination buttons are not connected to this source. This is an informative display about current status of the selected input (view only).

Step 2. Press and release the selected, green lighting destination button which has to be disconnected from the selected source. The pressed destination or multiple destinations will turn dark.

Step 3. Press and release TAKE button to execute disconnection.

Info *Deselected destinations are disconnected from any source, thus output devices will display black image or "no signal" message, or automatically will turn off.*

Info *Multiple switching and deselecting actions can be done simultaneously, during only one TAKE action.*

Creating a connection in AUTOTAKE mode

Step 1. Press and release the selected destination button. The pressed destination button, and the actually connected source button are illuminating green. If no source is connected (the output is muted) no source button will light up.

Step 2. Press and release the selected input button. The switch action will be executed immediately. Switching between sources to the selected destination can be done directly.

Deselecting or muting in AUTOTAKE mode

Step 1. Press and release the selected destination button. The pressed destination button, and the actually connected source button are lighting green. If no source is connected (the output is muted) no source button will light up.

Step 2. Press and release the active green lighting source button. The output is muted.

Info *Deselected destinations are disconnected from any source, thus output devices will display black or blue image or "no signal" message and may automatically turn off.*

PRELIMINARY VERSION!

3.2.5. Switching operations flowchart

To better understand the viewing and switching sequence in TAKE and AUTOTAKE modes, please study the below diagrams.

TAKE mode



Figure 3-1. Switching flowchart in TAKE mode

AUTOTAKE mode



Figure 3-2. Switching flowchart in AUTOTAKE mode

PRELIMINARY VERSION!

3.2.6. SAVE or LOAD PRESETS

The unit has 32 user programmable presets. Each preset stores a configuration regarding all input connections and mute state for all outputs. All presets are stored in a non volatile memory; the router keeps presets even in case of power down. Memory numbers are assigned to source buttons 1 to 16. The other presets are accessible only through software control (Serial or Ethernet).

Saving a Preset in TAKE mode

Step 1. Create the desired connections which have to be saved.

Step 2. Press and release the SAVE PRESET button.

Step 3. Press and release a source button according to the desired memory address (source 1 to 16 or to 12).

Step 4. Press and release TAKE button. Now the current configuration is stored in the selected memory.

Info *Preset save action always stores the current configuration for all outputs including mute state, but ignoring lock state.*

Loading a Preset in TAKE mode

Step 1. Press and release LOAD PRESET button.

Step 2. Press and release a source button according to the desired memory address (source 1 to 16 or to 12).

Step 3. Press and release TAKE button. Now the selected preset is loaded.

Info *Loading a preset modifies all output states that are not currently locked.*

Saving a Preset in AUTOTAKE mode

Step 1. Create the desired connections which have to be saved.

Step 2. Press and release SAVE PRESET button.

Step 3. Press and release a source button according to the desired memory address (source 1 to 16). Now the current configuration is stored in the selected memory.

Info *Preset save action always stores the current configuration for all outputs including mute state, but ignoring lock state.*

Loading a Preset in AUTOTAKE mode

Step 1. Press and release LOAD PRESET button.

Step 2. Press and release a source button according to the desired memory address (source 1 to 16). Now the selected preset is loaded.

Info *Loading a preset modifies all output states that are not currently locked.*

3.2.7. OUTPUT LOCK

Using Lightware routers it is possible to lock a destination's state. This feature prevents an accidental switching to the locked destination in case of important signal. Locking a destination means, that no input selection or muting can be executed on that particular destination.

Destinations can be independently locked or unlocked. Locking a destination does not affect other destinations.

PRELIMINARY VERSION!

View locked outputs in TAKE mode

Step 1. Press and release the Output Lock button.

Step 2. The Output Lock button and all the buttons of any locked destinations lights up, and remain illuminated for two seconds.

Lock an output in TAKE mode

Step 1. Press and release the Output Lock button.

Step 2. Now the Output Lock button lights up in red and all the locked output's buttons illuminate green (view state).

Step 3. If no button is pressed for three seconds, the router returns to idle state.

Step 4. If an unlit output button is pressed, it starts to blink, to indicate that it is preselected for output locking.

Step 5. Press and release TAKE button. The selected destinations are now locked.

Unlock an output in TAKE mode

Step 1. Press and release the Output Lock button.

Step 2. Now the Output Lock button lights up in red and all the locked output's buttons illuminate green (view state).

Step 3. If no button is pressed for three seconds, the router returns to idle state.

Step 4. If an illuminating output button is pressed, it goes off, to indicate that it is preselected for unlocking.

Step 5. Press and release TAKE button. The deselected destinations are now unlocked.

View locked outputs in AUTOTAKE mode

In AUTOTAKE mode a destination is selected all the time. Therefore the currently selected output and input buttons are illuminated. The Output Lock button illuminates regarding to the lock state of the current output.

Viewing all locked outputs is not possible is AUTOTAKE mode, as pressing the Output Lock button instantly locks or unlocks the current output.

Lock an output in AUTOTAKE mode

Step 1. Press and release the required destination button. Now the selected destination button and the currently configured source button light up (view mode).

Step 2. Press and release the Output Lock button. Now the Output Lock button lights up in red, and lock function is activated at once. No source can be changed at the locked destination.

Unlock an output in AUTOTAKE mode

Step 1. Press and release the required destination button which was previously locked. Now the selected destination button and the currently configured source button and the Output Lock button light up

Step 2. Press and release the Output Lock button (deselect). Now the Output Lock button turns off, and the locking function has been cancelled.

PRELIMINARY VERSION!

3.3. Remote operation

Lightware matrix routers can be controlled through various interfaces remotely. This makes possible to use such functions that are not accessible via the front panel. Also, this helps system integrators and operators to control multiple devices in a big system through a single user interface.

Available connections:

The available remote connections and the relating chapters are listed below.

User interface	Connection type		further information
	Ethernet port	RS-232 serial port	
Lightware matrix controller software	✓	✓	chapter 4 page 27
built-in website	✓	no	chapter 5 page 41
third party control system	✓	✓	chapter 7 page 50

Table 3-1. Available remote connections

Info *Ethernet port can be connected to a LAN hub, switch or router with a UTP patch cable. If connecting to a computer directly, a cross UTP cable has to be used!*

User interface comparsion

The built-in website and the Lightware matrix controller software have little different capabilities. The table below summarizes the main differences, helping you to select the interface that suits your needs.

Function	Matrix controller software	Built-in website
platform	Windows only	ANY ✓
installation	installation required	web browser needed only ✓
I/O and preset names	✓	no
Preview presets	✓	no
Easy EDID creator	✓	no
EDID editor	✓	no
EDID upload / download	✓	no

Table 3-2. User interface comparison

PRELIMINARY VERSION!

4. Software control – Using Lightware Matrix Controller

The matrix router unit can be controlled using Lightware Matrix Controller from a Windows PC or Laptop through RS-232 or Ethernet port.

4.1. Installing the Matrix Controller software

Step 1. Run Installer_LW_matrix_controller_v3_2_0.exe


Installer_LW_matrix_controller_v3_2_0 Setup: In...
Check the components you want to install and uncheck the components you don't want to install. Click Next to continue.
Select components to install:
LW Matrix Controller 3.2.0 (required)
Start Menu Shortcuts
Space required: 4.4MB
Cancel
Nullsoft Install System v2.37
Next >

Step 2. Select destination folder and click Install (Using the default path is highly recommended)


Installer_LW_matrix_controller_v3_2_0 Setup: In...
Setup will install Installer_LW_matrix_controller_v3_2_0 in the following folder. To install in a different folder, click Browse and select another folder. Click Install to start the installation.
Destination Folder
C:\Program Files\Lightware\
Browse...
Space required: 4.4MB
Space available: 89.7GB
Cancel
Nullsoft Install System v2.37
< Back
Install

Step 3. If you want to create desktop icon click Yes in the next pop-up window:



PRELIMINARY VERSION!

Step 4. After finishing the installation of Lightware Matrix Controller the following message appears:

Step 5. To run Lightware matrix control software find the shortcut icon in Start menu → Programs → Lightware → LW_matrix_controller_vXXX or on the desktop, and double click:

Uninstalling

To uninstall the control software double click on: Start menu → Programs → Lightware → Uninstall_LW_matrix_controller_vXXX.exe

PRELIMINARY VERSION!

4.2. Establishing the connection

The unit can be controlled from a Windows computer using Lightware Matrix Controller software through RS-232 connection or Ethernet port.

Step 1. Connect the matrix switcher and the computer via

- serial port, with standard RS-232 Male to Female cable
- Ethernet (with a HUB or to a simple endpoint)
- Ethernet directly (with cross UTP cable)

Step 2. Start the application

To run the CONTROL SOFTWARE double click on the icon of the software on the desktop or select proper shortcut from Start Menu → Programs → Lightware folder.



Figure 4-1. Matrix Controller software startup

PRELIMINARY VERSION!

Step 3. The Find dialog appears automatically

If the connection has been made via Ethernet, you can select the desired card to query the LAN for Lightware devices (if the PC has more Ethernet cards installed). The device type and the serial number are displayed automatically. Select the desired IP address.

No IP address will be shown if no LAN enabled Lightware matrix switcher is connected to the same network that the PC is connected to.

If the connection has been made via serial port, select the appropriate communication port. To query the selected COM port for the device type and serial number double click on then desired COM port.



Figure 4-2. Ethernet connection



Figure 4-3. Serial connection

Step 4. Click on the Connect button to connect to the device

Info: *Only one user is allowed to connect to the matrix switcher via Ethernet.*

Info: *Be sure that the firewall is not blocking the application!*

PRELIMINARY VERSION!

When the Lightware Matrix Controller finds the hardware, it determines the product type, and the control menu appears. The current state of the crosspoint switch is displayed.



Figure 4-4. Matrix controller crosspoint array

4.3. Control menu

This menu contains the crosspoint area and the preset area. After connecting to a new device, this menu appears by default.

This view adapts to the input and output numbers of the router. I1; I2; I3... columns represent the inputs, the O1; O2; O3...rows represent the outputs. Each green square represents a valid connection. Since an input can be routed to more outputs simultaneously, there can be one or more green squares in one column. However an output can be switched to only one input, so there can be only one green square in any row.

4.3.1. Switch, mute and lock

For making a connection click on the desired square. If the output port is not locked or muted, the connection will be made. For switching an input to all outputs, click with the left mouse button on the input label, and click "Switch to all outputs" from the popup menu.

Outputs can be easily muted by clicking on the button titled 'M' beside the output. This means that no signal is present at this output. If mute is active, the color of the button's background changes to black.

Outputs can be locked to any input. After locking an input to an output, no switching is permitted to this output unless it is unlocked again. If output lock is active, the color of the button's background changes to red.

Info: *Loading a preset doesn't alter either the lock state or the switch state of a locked output. If an output is locked to an input before preset loading it will also be locked to that input after preset loading, so locked outputs ignore the preset.*

PRELIMINARY VERSION!

4.3.2. Input and output card types

With Lightware Hybrid Technology the matrix frames can be equipped with different types of cards. The colored bars near the crosspoint area display the type of the card in each slot. Whether it is an optical, a twisted pair or other kind of card, a different color represents it's type.

Info *Since this product model is a compact built system, the cards cannot be changed.*

Legend for card types:

MX-DVI-D card

4.3.3. Input and output names

To help memorizing the connected sources and destinations, names can be assigned to inputs and outputs. I/O names can be maximum 16 characters long, and can contain any ASCII characters except: ( ) { }. All characters are converted to uppercase.

Info: *If the CPU firmware version is above 2.4.3 then the I/O names are stored in the router's memory so they can be read by any other computer. Otherwise, the I/O names are stored locally in a file on the computer that was used to save the I/O names.*

Rename I/O port

Step 1. Click on the desired input or output.

Step 2. Click RENAME in the popup menu. The Rename window appears.

Step 3. Type the desired name, and click Apply.

Read I/O names

I/O names are loaded automatically when connection to the router is established. However I/O names can be re-read manually as well.

Step 1. Click on any input or output.

Step 2. In the popup menu click Read I/O names.

4.3.4. PRESET operations

Preset operations can be done on the PRESET panel. The panel can be accessed by clicking on the arrow at the right margin of the software window. Each Lightware matrix switcher has 32 preset memories that can be loaded and saved at any time.

Info: *A preset setting stores a full configuration of all outputs, so preset loading have an effect on every output, except the locked ones.*

PRELIMINARY VERSION!

Load preset



Step 1. Select the preset memory (Preset1...Preset32) you want to load as the next configuration.

Step 2. Press LOAD PRESET button or right click on the desired preset, and click Load in the popup menu. Now the preset is loaded.

Step 3. The new I/O configuration is displayed on the matrix switching area.

Save preset

Step 1. Make the desired configuration on the matrix switching area.

Step 2. Select the preset memory (Preset1...Preset32) where you want to save your current configuration.

Step 3. Press SAVE PRESET button or right click on the preset and click Save in the popup menu. Now the preset is stored.

Preview preset

Step 1. Right click on the desired preset, and click Preview in the popup menu.

Step 2. The preset's I/O configuration is displayed on the matrix switching area with yellow squares for two seconds.

Rename preset

To help memorizing the preset configurations, names can be assigned to saved presets. Preset names can be maximum 16 characters long, and can contain any ASCII characters except: ( ) { }. All characters are converted to uppercase.

Step 1. Select the preset memory (Preset1...Preset32) you want to rename.

Step 2. Click RENAME... in the popup menu. The Rename window appears.

Step 3. Type in the desired name and click APPLY. Now the new preset name is stored.

Info: *If the CPU firmware version is above 2.0.0 then the preset names are stored in the router's memory so they can be read by another computer. Otherwise, the preset names are stored locally in a file on the current computer.*

PRELIMINARY VERSION!

Read preset names

The control software downloads the names automatically upon establishing connection to the matrix. Preset names can be re-read manually by clicking on the READ PRESET NAMES button in the preset area.

Info: *If the CPU firmware version is above 2.0.0 then the preset names are stored in the router's memory so they can be read by another computer. Otherwise, the preset names are stored locally in a file on the computer that was used to save the preset names.*

4.3.1. Output parameter settings

By right clicking on an output label a dialog window appears showing the parameters for the corresponding output. Some settings are only accessible with Lightware PRO series routers.

Scope of changes

There are two options to apply changes. To set the scope of the changed settings, select the desired option in the top left box.

Apply changes to current output: this option means the modified parameters are applied only to the currently selected port.

Apply changes to all outputs: this option means that the modified parameters are applied to all output ports.

Info: *After closing this window, the Current Output option will be selected regardless of which was active at the time of closing. It is to avoid setting All Outputs by mistake.*

Reload factory defaults

Current output: Reloads the default values to the currently selected output.

All outputs: Loads the factory default values to all outputs.

Drive current

It specifies the drive current of the internal crosspoint circuit. It is strongly recommended to leave this value at the default 12 mA setting.

This setting does not affect the output directly, only an internal signal. Modifications are done promptly when selecting a value from the drop down list.

4.4. EDID menu

By clicking on the **EDID** menu, the EDID router window appears. This view is divided in two segments. The upper segment can be opened by clicking the green arrow. This segment contains the EDID editor. The lower segment is the EDID router area. This consists of two list windows, which can display a selected part of the EDID memory.

Info *When the user enters the menu for the first time, the software starts to download the whole EDID list from the matrix. It may take about 30-40 seconds.*

PRELIMINARY VERSION!

4.4.1. EDID Router operation

After the list is downloaded, the current status is shown. The EDID memory consists of four parts. Any memory part can be displayed on either side by using the drop down lists.

The **Emulated EDID List** shows the currently emulated EDIDs for each input. It contains the resolution, manufacturer and vendor name of the EDID reported to the sources for each input separately. The source column displays the memory location that the current EDID was routed from (Mem0 is shown as source if the source was changed after it was copied to an input). The rows with red background are dynamically routed to the input.

The **Last attached Monitor's EDID List** contains the resolution, manufacturer and vendor name of the display devices connected to matrix switcher's output. The matrix remembers the last display device's EDID, so there is an EDID shown even if there is no device attached to the router's output at the moment.

The **Factory EDID List** shows the factory memory locations (01# - 50#) with preprogrammed EDID.

The **User EDID List** shows the memory locations (51# - 100#) which can be used by the user to save custom EDIDs.



Figure 4-5. EDID Management menu

Any DVI source reads the EDID from the Emulated EDID memory for the corresponding port. The user can copy an EDID from any of the three EDID lists to the desired input's memory location. This is called EDID routing. There are two types of the emulation: static and dynamic.

- Static EDID emulation happens, when an EDID from the Factory or User EDID list is routed to an input
- Dynamic EDID emulation occurs, when an attached monitor's EDID is routed to an input. In this case the emulated EDID changes automatically, if a new monitor is attached to the output, by simply copying the data from the monitor.

Changing the emulated EDID at one or all inputs

Step 1. Select the Emulated EDID List in one of the list window areas in the drop down list.

Step 2. Select the desired EDID list in the other list window from which you want to copy (route) the EDID.

Step 3. To change the emulated EDID at

a) one input, drag and drop the EDID to the desired input location.

b) all inputs at the same time, right click on the desired new EDID and select "Switch to all Inputs" from the pop-up menu.

PRELIMINARY VERSION!

Step 4. Click Yes in the pop-up dialog window to confirm EDID change.

Info: *If dynamic emulation is established, the emulated EDID will be changed on all inputs that are affected, every time a new monitor is connected to the output which was the source of the dynamic EDID routing. If the monitor is disconnected from the output, the latest EDID remains, it will not be deleted from the input. This feature helps especially rental technicians or system integrators to keep the source continuously transmitting the signal, and adopt the system for new incoming display devices.*

Info: *Power ON/OFF cycle will not affect the emulated EDID or other settings.*

Info: *EDID routing procedure causes a status change, hence it is reported back to the CONTROL SOFTWARE within 2-3 seconds.*

Learning EDID from attached display device

The system is able to learn the EDID from a connected display device and store it in one of the user programmable memory locations.

Step 1. Select the User Memory in the drop-down menu in one of the list windows.

Step 2. Select the EDID to be saved from the other list window.

Step 3. Drag and drop the selected EDID to the desired User Memory location.

Step 4. Click Yes in the pop-up dialog window to confirm EDID change.

Saving EDID from memory to file

The control software is able to download EDID from the matrix and to save it as an EDID file.

Step 1. Right click on the EDID to be saved.

Step 2. Click on the “Save to file” in the pop-up window.

Step 3. The Matrix Controller Software downloads the desired EDID and a save dialog appears. It may take a few seconds to download the EDID. If the save dialog is shown, type in the file name, and press Save button. After the process was completed, an “EDID saved!” message confirms the command.

Load EDID from file to memory

The system is able to load EDID from a file located on the computer and store it in the matrix. EDID are stored in *.dat files.

Step 1. Select the User Memory list in one of the list windows

Step 2. Right click on the desired memory location. Then select “Load from file” from the pop-up menu.

Step 3. Browse your hard drive to find the desired EDID file. The software checks whether the selected file is a valid EDID file.

Step 4. Click Open in the browser window. After the process finished, ”EDID Upload completed” message appears.

PRELIMINARY VERSION!

Synchronizing EDID lists

By clicking "Synchronize EDID List" button the Lightware Matrix Controller software rereads all EDID information from the connected matrix switcher. During normal operation it is not necessary to use this function because the matrix switcher always reports every status change automatically.

Info: *There is always a small delay in responses. So if a new monitor is connected to the output its new EDID is not shown immediately but in 2-3 seconds!*

Info: *As the matrix switcher reports status change nothing will happen if you select the same EDID to a given input or connect the same display device to a given output!*

4.4.2. Advanced EDID Editor

The Lightware Advanced EDID Editor is integrated into the Lightware Matrix Controller software. By clicking on the green arrow, the editor area rolls down.

When the user enters the menu for the first time, an empty EDID is loaded into the editor's memory.

All EDIDs in the router's memory can be edited in the following way:

Step 1. Right click on the desired EDID to be loaded to the EDID Editor.

Step 2. In the pop-up menu, click on Edit EDID. The editor area automatically rolls down, and the EDID is loaded into the editor area.

For further information, see the user's manual of Advanced EDID Editor.

PRELIMINARY VERSION!

4.5. Terminal menu



This general-purpose serial terminal is intended mainly for test and debug purposes. After a successful connection is established with a router this terminal can be used either via serial or TCP/IP connection. All commands can be used here that are discussed in *Programmer's reference*, chapter *7*, on page *50*. The text can be typed directly.

By default commands are automatically surrounded by framing brackets. Every sent command and every received response gets an arrow (-> or <-) prefix, and has different font colors in order to help distinguishing.

If the "Command framing" checkbox is unchecked, you can send multiple commands together, however in this case you have to type in the framing brackets manually.

4.6. STATUS menu

Basic device information, such as the installed cards' firmware and hardware revisions are displayed in this window.



Figure 4-6. Status menu

Info: *If the device is connected via RS-232, the IP address field shows "serial connection" instead of the IP address.*

If the matrix is connected via IP connection, the serial and IP settings can be viewed by clicking on the "Serial and IP Settings..." button.

PRELIMINARY VERSION!

4.6.1. IP settings

Obtain IP address automatically

By selecting the "Obtain IP address automatically" option, the matrix gets the IP address from the DHCP server on the LAN, or if DHCP server is not present, it gets an AutoIP address from the 169.254.xxx.xxx domain.

Fix IP configuration

In this case, the matrix has an IP address configuration set up by the user/administrator.

Step 1. Select the "Fix IP configuration" option.

Step 2. Type in the IP address, select the desired subnet mask and type in the gateway IP address. The current configuration is in brackets.

Step 3. Click on "Apply Settings" button. Depending on the modified settings, you might need to restart the router and the Matrix Controller Software.



Info: *The "Load Default" button loads the factory default IP settings to the fields, which contain a fix configuration:*

IP Address: 192.168.254.254
Subnet Mask: 255.255.0.0
Default Gateway: 0.0.0.0

IP port settings

The router can be accessed via this TCP/IP port number with TCP connection. This number can be modified to any number between 1025 - 65535 except the followings: 9999, 14000 - 14009, 30704, and 30718.

The port 23 is accepted for Barco Encore. To use the matrix with the Vista Spyder set port to 10001.

Info: *The IP port number is 10001 by default.*

PRELIMINARY VERSION!

TCP-serial configuration

For informational purposes, the properties of the TCP-serial interface are displayed. This is a communication interface from the embedded Ethernet device towards the main CPU.

The “Reset” button resets these values to the factory default, and has a safety purpose only.

In the normal operation there is no need to reset these values. The above picture shows the factory default values in normal operation.

4.7. Find menu

By clicking this menu, the available devices can be rescanned on the serial port and on the Ethernet. If the Matrix Controller Software has a live connection to a device on a port, a question window appears, asking if you really want to search for devices.

Clicking Yes will open the Find window. See section *4.2* about *establishing the connection* on page *29*.

Clicking No will close the pop up window, the original connection remains active.

PRELIMINARY VERSION!

5. Web control – Using built-in website

5.1. Accessing the router's built-in website

Lightware matrices have a built-in web page, which can be accessed over TCP/IP protocol and offers you full control over all settings even if you don't have the opportunity to install new programs. The router web is compatible with most widely spread browsers and requires no additional software components such as ActiveX controls. The web interface functionality has been tested and confirmed with the following browsers:

- Mozilla Firefox 2 and 3 (recommended)
- Internet Explorer 6, 7 and 8
- Opera 8 and 9
- Safari 3
- Google Chrome 2.0

To access the webpage just run your preferred web browser and type the IP address of the router as URL.

Info: *The web page is not compliant with Google Chrome 1.0.*

Info: *Only one opened web page is allowed simultaneously. Other TCP/IP connections are prohibited while the web page is opened. Using more instances of the web page simultaneously will result in inadequate operations.*



Figure 5-1. Built-in website main page

PRELIMINARY VERSION!

5.2. Menu description

The built-in website contains the following menus and submenus:

Control

The Control Menu has two submenus.

Set and View Crosspoints

This menu appears by default, when accessing the website.

It contains a matrix button area according to the input and output numbers of the router. Columns are representing the inputs, while rows are the outputs. The green squares represent the state of the matrix switcher.

The Preset selection box is on the right side of this page.

Output Settings

This menu contains advanced settings for output parameters. Some settings are only accessible with Lightware PRO series routers.

EDID Management

By clicking on this menu, the built-in website downloads the EDID list from the matrix. The user can view and modify the EDIDs.

Status

Basic device information such as the serial number, installed cards firmware, and hardware versions are displayed on this page.

Configuration

This page shows the current network configuration of the matrix, such as IP settings and port number.

Support

The contact information to Lightware Visual Engineering is shown in this page.

PRELIMINARY VERSION!

5.3. Control menu

5.3.1. Crosspoint switching

Click on **Control** menu then select **Set and View Crosspoints.**



Figure 5-2. Built-in website crosspoint array

1; 2; 3… columns represent the inputs, and the 1; 2; 3… rows represent the outputs. Each green square represents a live connection. For making a connection click on the desired grey square. When the mouse pointer hovers over the array, the corresponding input and output numbers are highlighted in red to help switching.

Mute outputs

Outputs can be easily muted by clicking the button titled 'M' beside the output. This means that no signal will be present at this output. If muting is active the background turns to black.

Lock outputs

Outputs can be locked to any inputs. After locking an input to an output no switching is permitted for this output unless it is unlocked again. If lock is active, background turns to red.

Info *Loading a preset doesn't change neither the lock state nor the switch state of a locked output. If an output is locked to an input before preset loading, it will also be locked that input after preset loading, so locked outputs ignore the preset.*

5.3.2. Preset operations

Preset operations can be done in the right panel of the **Control → Set and View Crosspoints** page. Each Lightware matrix switcher has 32 preset memories that can be loaded and saved any time.

Front panel Preset operations effect only the first 16 preset memories, all others from 17 to 32 are available only via Matrix Controller software and built-in website.

PRELIMINARY VERSION!

Save Preset

Step 1. Make the desired configuration on matrix switching area.

Step 2. Select the preset memory location (Preset1...Preset32) where you want to save your configuration to.

Step 3. Press Save Preset button. Now a message box appears that the preset is stored.

Load Preset

Step 1. Select the preset memory location (Preset1...Preset32) you want to load as next configuration.

Step 2. Press Load Preset button. Now the preset is loaded

Step 3. The new I/O configuration is displayed on the matrix switching area.

5.3.3. Output settings

Click on **Control** menu then select **Output settings.** This menu contains advanced settings for output parameters. Some settings are only accessible with Lightware PRO series routers.

Scope of changes

The affected output can be selected in the top box, or changes can be applied to all outputs. To set the scope of the changed settings, select the desired option in the top left box.

Apply changes to current output: this option means the modified parameters are applied only to the currently selected port.

Apply changes to all outputs: this option means that the modified parameters are applied to all output ports.

Info: *After closing this window, the Current Output option will be selected regardless of which was active at the time of closing. It is to avoid setting All Outputs by mistake.*

Reload factory defaults

Current output: Reloads the default values to the currently selected output.

All outputs: Loads the factory default values to all outputs.

Drive current

It specifies the drive current of the internal crosspoint circuit. It is strongly recommended to leave this value at the default 12 mA setting.

This setting does not affect the output directly, only an internal signal. Modifications are done promptly when selecting a value from the drop down list.

PRELIMINARY VERSION!

5.4. EDID Router operation

By clicking on the **EDID Management** menu, the EDID router page appears.

When the user enters the menu first, the built-in website starts to download the whole EDID list from the matrix. It may take up to 30 seconds for the first time.

After the list is downloaded, the current status of the router's EDID is shown on the three boxes.

The **Emulated EDIDs** box contains the resolutions and the vendor names of the EDID reported to the source for each input separately.

The **Last attached Monitor's EDIDs** box contains the resolutions and vendor names of the display devices connected to matrix switcher's output.

The **EDID list** box contains all the available EDIDs stored in the matrix memory.

5.4.1. Change emulated EDID at one or all inputs

All EDIDs are enumerated in the **EDID list** window.

Step 1. Select the desired EDID from this list with a left mouse click, a popup menu appears.

Step 2. Click the "Switch this EDID to" item. A popup menu appears with an input name list.

Step 3. Click on the desired input, or on the ALL text. Now the EDID has been changed on selected input as the message box shows on the left corner.



Figure 5-3. Static EDID routing

Info: *Switching to ALL inputs may take several seconds*

PRELIMINARY VERSION!

The user can switch and learn EDIDs also in the **Last Attached Monitors EDIDs** window. In this case dynamic EDID routing is established.



Figure 5-4. Dynamic EDID routing

5.4.2. Learn EDID from attached display device

The matrix switcher can learn the EDID from a connected display device and store it in one of the user programmable memory locations. All the monitor's EDIDs are listed in the **EDID list** window, and also in the **Last Attached Monitors EDIDs** window.

Step 1. Click the desired monitor's EDID from the list.

Step 2. Click the Learn this EDID to submenu item. A popup window will show the memory locations from 50 to 100, which are available for the user.

Step 3. Click on the desired memory location. The built-in website refreshes the lists in a few seconds, and a massage box indicates the change.



Figure 5-5. Learning EDID from display device

5.5. Status

Basic device information, such as the installed cards' firmware and hardware revisions are displayed in this window.

PRELIMINARY VERSION!

5.6. Network Configuration

The unit's network values are displayed when you select **Configuration → Network Settings**.

Info: *It is possible to reload factory default IP setup by front panel buttons. See section 7.3 on page 50 about this.*

5.6.1. Automatic IP Address Configuration

The matrix switcher supports three of the most used automatic IP configuration protocols.

To assign IP address automatically:

Step 1. Click on Configuration menu

Step 2. Select Network Settings

Step 3. Select Obtain IP address automatically

Step 4. Enter the following (as necessary):



BOOTP Select ***Enable*** to permit the Bootstrap Protocol (BOOTP) server to assign the IP address from a pool of addresses automatically.

DHCP Select ***Enable*** to permit the Dynamic Host Configuration Protocol (DHCP) server to assign leased IP address to the matrix unit automatically.

AutoIP Select ***Enable*** to permit the matrix to generate an IP in the 169.254.x.x address range with Class B subnet.

Info: *Disabling BOOTP, DHCP, and AutoIP (all three checkboxes) is not advised as the only available IP assignment method will then be ARP or serial port.*

Step 5. When you are finished, click Apply Settings button

Info: *To continue using the built-in website, you must type in the IP address in your browser.*

5.6.2. Static IP address configuration

The user can manually assign an IP address to the unit, and enter related network settings.

To assign an IP address manually:

Step 1. Click on Configuration menu

Step 2. Select Network Settings

Step 3. Select Fix IP Configuration

PRELIMINARY VERSION!

Step 4. Enter the following (as necessary):

IP Address	If DHCP is not used to assign IP addresses, enter it manually in decimal-dot notation. The IP addresses must be set to a unique value in the network.
Subnet Mask	A subnet mask defines the number of bits taken from the IP address that are assigned for the host part.
Default Gateway	The gateway address, or router, allows communication to another LAN segments. The gateway address should be the IP address of the router connected to the same LAN segment as the matrix. The gateway address must be within the local network.

Step 5. When you are finished, click Apply Settings button

Info: *To continue using the website, you must type in the IP address to the browser.*

5.6.3. Loading the default IP settings

Step 1. Click on the Load Default button. Now the factory default IP address, Subnet Mask and Gateway address is loaded into the input boxes. But they are not saved.

Step 2. To save the settings, click on Apply Settings button.

5.6.4. TCP Port Configuration

The user can configure the TCP port number, which is used to communicate with the matrix router through LAN. The input box initially contains the current setting.

Step 1. Type the desired TCP port number into the input box

Step 2. Press the Apply Settings button. The new port will be active after the next connection.

5.6.5. Loading the default TCP Port settings

Step 1. Click on Load Default button. Now the factory default value is in the input box, but it is not saved.

Step 2. To save, click on Apply Settings button. The new port will be active after the next connection.

5.7. Support

For technical support, please don't hesitate to contact Lightware Visual Engineering at support@lightware.hu.

PRELIMINARY VERSION!

6. About EDID memory

EDID router contains a 164 block non volatile memory bank. EDID memory is structured as follows:

1..50 ..... Factory Preset EDID list

51..100 ..... User programmable memories

101..116 (DVI_OUT_1...16)..... Last attached monitor's EDID list

133..148 (DVI_IN_1...16)..... Emulated EDID at input connectors

All EDID (including factory preset; user programmable memories; EDID at other inputs; and EDID at outputs) can be switched and emulated at any of the inputs.

Info *The first 50 EDID (1…50 inclusive) are factory preprogrammed and cannot be modified. These are the most commonly used resolutions.*

Info *Memory locations 117..132 and 148..164 are reserved for 32x32 matrix configurations only, therefore not accessible in this matrix router.*

Info *MX16x16DVI-Slim and MX12x12DVI-Slim can handle both 128 Byte EDID and 256 Byte extended EDID structures.*

Info *The attached monitor's EDID is stored automatically, until a new monitor is attached to that particular output. In case of powering the unit off, the last attached monitor's EDID remains in non volatile memory.*

MEMORY	Resolution		MEMORY	Resolution
01	640 x 480 @ 60.0 Hz		26	1600 x 1200 @ 50.0 Hz
02	640 x 480 @ 75.0 Hz		27	1600 x 1200 @ 60.0 Hz
03	848 x 480 @ 60.0 Hz		28	1920 x 1200 @ 59.55 Hz
04	800 x 600 @ 50.0 Hz		29	1920 x 1200 @ 50.0 Hz
05	800 x 600 @ 60.30 Hz		30	1440 x 480i @ 60.3 Hz
06	800 x 600 @ 74.99 Hz		31	640 x 480 @ 59.94 Hz
07	1024 x 768 @ 49.98 Hz		32	720 x 480 @ 59.92 Hz
08	1024 x 768 @ 60.0 Hz		33	1440 x 576i @ 50.6 Hz
09	1024 x 768 @ 75.2 Hz		34	720 x 576 @ 50.0 Hz
10	1152 x 864 @ 75.0 Hz		35	1280 x 720 @ 50.0 Hz
11	1280 x 768 @ 50.0 Hz		36	1280 x 720 @ 60.0 Hz
12	1280 x 768 @ 59.92 Hz		37	1920 x1080i @ 50.3 Hz
13	1280 x 768 @ 75.0 Hz		38	1920 x1080i @ 50.0 Hz
14	1360 x 768 @ 60.1 Hz		39	1920 x1080i @ 60.5 Hz
15	1364 x 768 @ 50.0 Hz		40	1920 x 1080 @ 24.0 Hz
16	1364 x 768 @ 59.93 Hz		41	1920 x 1080 @ 24.99 Hz
17	1364 x 768 @ 74.98 Hz		42	1920 x 1080 @ 30.0 Hz
18	1280 x 1024 @ 50.0 Hz		43	1920 x 1080 @ 50.0 Hz
19	1280 x 1024 @ 60.1 Hz		44	1920 x 1080 @ 49.99 Hz
20	1280 x 1024 @ 75.1 Hz		45	1920 x 1080 @ 60.0 Hz
21	1366 x 1024 @ 59.99 Hz		46	2048 x 1080 @ 49.99 Hz
22	1400 x 1050 @ 49.99 Hz		47	2048 x 1080 @ 50.0 Hz
23	1400 x 1050 @ 59.99 Hz		48	2048 x 1080 @ 59.99 Hz
24	1400 x 1050 @ 75.0 Hz		49	1920 x 1200 @ 59.55 Hz
25	1680 x 1050 @ 59.99 Hz		50	2560 x 1600 @ 59.85 Hz

Table 6-1. Factory preset EDID list

PRELIMINARY VERSION!

7. Programmer's reference

Users can connect the matrix through Ethernet, or serial port as well. After establishing connection, there is no difference between connection types (except some rare cases, which are uniquely noted).

Lightware matrix routers can be controlled with external devices which can communicate according to the router protocol. Lightware routers have a special protocol, but to interoperate with third party devices, a secondary protocol is also provided.

7.1. Changing and viewing protocols

The router is equipped with multiple router protocols.

Step 1. Switch the router to TAKE mode if used previously in AUTOTAKE mode by pressing TAKE button for 4 seconds. (light will go off)

Step 2. Press and release Control Lock (Control Lock button lights in up red continuously)

Step 3. Press and keep pressed the Output Lock button. Now one of the source buttons will light up according to the current protocol (view protocol):

a) If Source#1 button lights: Lightware protocol is active

b) If Source#2 button lights: Protocol#2 is active

Step 4.

a) If you do not want to change the protocol, release the Output Lock button (view only) .

b) If you want to change the protocol, keep the Output Lock button pressed, and press the desired Source button, accordingly to the new protocol. The desired Source button starts blinking, the router performs a reset straight away and all buttons light up for 3 seconds. Now the new protocol is active.

7.2. Serial port settings

MX16x16DVI-Slim and MX12x12DVI-Slim can be ordered with either RS-232 or RS-422 communication port. The port settings are done in the factory. D-SUB connector pin assignments can be found in chapter *2.4.4* on page *19*.

The device uses standard RS-232 interface with the following settings:

9600 Baud

8 data bit

1 stop bit

no parity

null modem cable

7.3. Ethernet port settings

The unit's Ethernet port can be set to factory default IP configuration or to DHCP mode with front panel buttons. To set the IP configuration perform the following:

Step 1. Ensure that there is no active connection on the Ethernet port. (unplugging the LAN cable is the most secure)

PRELIMINARY VERSION!

Step 2. Switch the router to TAKE mode if used previously in AUTOTAKE mode by pressing TAKE button for 4 seconds (light will go off).

Step 3. Press and release Control Lock (Control Lock button lights in up red continuously).

Step 4. Press and keep pressed the Output Lock button (the current protocol indication will light up).

Step 5. Press and release the

a) **Load Preset** button to set the **factory default IP** settings

IP address:	192.168.254.254
port number:	10001
subnet mask:	255.255.0.0
gateway:	0.0.0.0

b) **Save Preset** button to set **DHCP enabled**

IP address:	Acquired with DHCP
port number:	unchanged
subnet mask:	unchanged
gateway:	unchanged

Step 6. A light sequence will occur to confirm the command. (Save Preset, Load Preset and Take/Auto buttons will light up one after the other)

Step 7. Reinsert the LAN cable to the Ethernet port if it was unplugged.

Step 8. Wait about 20 seconds before connecting the router via Ethernet.

7.4. Protocol description

The protocol description hereinafter stands for Lightware protocol.

The matrices accept commands surrounded by curly brackets - { } - and responds data surrounded by round brackets - ( ) - only if a command was successfully executed. All input commands are converted to uppercase, but respond commands can contain upper and lower case letters as well.

Legend for control commands:

<in>	=	input number in 1 or 2 digit ASCII format (01,5,07,16 etc.)
<out>	=	output number in 1 or 2 digit ASCII format
<in²>	=	input number in 2 digit ASCII format (01, 02, 10, 12 etc.)
<out²>	=	output number in 2 digit ASCII format (01, 02, 10, 12 etc.)
<loc>	=	location number in 1, 2 or 3 digit ASCII format
<id>	=	id number in 1 or 2 digit ASCII format
<id²>	=	id number in 2 digit ASCII format
CrLf	=	Carriage return, Line feed (0x0D, 0x0A)
•	=	space character (0x20)
→	=	each command issued by the controller
←	=	each response received from the router

PRELIMINARY VERSION!

7.5. Switching and control commands

7.5.1. Switch one input to one output

Description: Switch input <in> to output <out>.

Format	Example
Command {<in>@<out>}	→ {1@5}
Response (O<out²>●I<in²>)CrLf	← (O05 I01)CrLf

Explanation: Input 1 is switched to output 5.

7.5.2. Switch one input to all outputs

Description: Switch input <in> to all outputs.

Format	Example
Command {<in>@O}	→ {02@O}
Response (I<in²>●ALL)CrLf	← (I01 ALL)CrLf

Explanation: Input 2 is switched to all outputs.

7.5.3. View connection on the specified output

Info *Obsolete! Use {VC} instead*

Description: View connection on output <out>.

Format	Example
Command {?<out>}	→ {?05}
Response (O<out²>●I<in²>)CrLf	← (O05 I01)CrLf

Explanation: Viewing connection for output 5. The connected input is 1.

Info *If the output is locked, muted, or both locked and muted, the response format changes. If the output is muted you get a letter 'M', if locked a letter 'L' and if muted and locked at the same time 'U' before the 2 digit numbers (e. g. O05 IL01).*

7.5.4. View connection on all outputs

Description: Viewing all outputs' connection results in different response length, because it depends on the router's type (length = 16 for MX16x16DVI-Slim, length = 12 for MX12x12DVI-Slim). The response below supposes a router having 16 outputs.

Format	**Example 1** (MX16x16DVI-Slim)
Command {VC}	→ {VC}
Response (ALL●<O1>●<O2>●<O3> ●<O4>●<O5>●<O6>●<O7> ●<O8>●<O9>●<O10> ●<O11>●<O121>●<O13> ●<O14>●<O15>●<O16>)CrLf	← (ALL 02 02 02 05 05 05 08 08 08 08 08 08 08 08 08 08)CrLf

Legend 1: All <Ox> indexes show the corresponding output's connection state. If value <O5> equals 04 it means that output 5 is connected to input 4. <O1>..<O8> are two digit ASCII characters. (01, 02, 04, etc.)

Explanation 1: Viewing connection for all outputs. Input 2 is connected to outputs 1, 2 and 3. Input 5 is connected to outputs 4, 5 and 6. Input 8 is connected to outputs 7 through 16.

PRELIMINARY VERSION!

Info *If an output is locked, muted, or both locked and muted, the response format changes. If outputs are muted you get a letter 'M', if locked a letter 'L' and if muted and locked at the same time 'U' before the 2 digit numbers.*

Format		Example 2 (MX16x16DVI-Slim)
Command	{VC}	→ {VC}
Response	(ALL●<O1>●<O2>●<O3> ●<O4>●<O5>●<O6>●<O7> ●<O8>●<O9>●<O10> ●<O11>●<O121>●<O13> ●<O14>●<O15>●<O16>)CrLf	← (ALL M02 L02 U02 05 05 05 08 08 08 08 08 08 08 08 08 08)CrLf

Legend 2: Any <Ox> indexes can be a two digit number, or there can be a leading character showing the mute and/or lock state for the corresponding output.

Index	Legend	Explanation
<Ox>	<in²>	<Ox> is connected to <in²>, <Ox> neither muted nor locked.
<Ox>	M<in²>	<Ox> is connected to <in²>, <Ox> is muted, and unlocked.
<Ox>	L<in²>	<Ox> is connected to <in²>, <Ox> is not muted, but locked.
<Ox>	U<in²>	<Ox> is connected to <in²>, <Ox> is muted and locked.

Explanation 2: Viewing connection for all outputs. Input 2 is connected to outputs 1, 2 and 3. Output 1 is muted. Output 2 is locked. Output 3 is muted and locked. Input 5 is connected to outputs 4, 5 and 6. Input 8 is connected to outputs 7 through 16.

7.5.5. View mutes on all outputs

Description: Viewing all outputs' connection results in different response length, because it depends on the router's type (length = 16 for MX16x16DVI-Slim, length = 12 for MX12x12DVI-Slim). The response below supposes a router having 16 outputs.

Format		Example (MX16x16DVI-Slim)
Command	{VM}	→ {VM}
Response	(MUT●<M1>●<M2>●<M3> ●<M4>●<M5>●<M6>●<M7> ●<M8>●<M9>●<M10> ●<M11>●<M12>●<M13> ●<M14>●<M15>●<M16>)CrLf	← (MUT 1 0 1 1 0 0 0 0 0 0 0 0 0 0 0 0)CrLf

Legend: All <Mx> indexes are one digit numbers, showing the mute state for the corresponding output. If <Mx> equals 0 the output x is unmated. If <Mx> equals 1, the output x is muted.

Explanation: Output 1, 3 and 4 are muted, the other outputs are not muted.

7.5.6. Mute specified output

Description: Mute output <out>.

Format	Example
Command {#<out>}	→ {#03}
Response (1MT<out²>)CrLf	← (1MT03)CrLf

Explanation: Output 3 is muted. Now no signal presents on output 3.

PRELIMINARY VERSION!

7.5.7. Unmute specified output

Description: Unmute output <out>.

Format	Example
Command {+<out>}	→ {+03}
Response (0MT<out²>)CrLf	← (0MT03)CrLf

Explanation: Output 3 is unmuted. Now output 3 is switched to the input it was connected to prior to the mute command.

7.5.8. Lock specified output

Description: Lock output <out>. Output's state cannot be changed until unlocking.

Format	Example
Command {#><out>}	→ {#>05}
Response (1LO<out²>)CrLf	← (1LO05)CrLf

Explanation: Output 5 is locked.

7.5.9. Unlock specified output

Description: Unlock output <out>. Now output 3 state can be changed.

Format	Example
Command {+<<out>}	→ {+<05}
Response (0LO<out²>)CrLf	← (0LO05)CrLf

Explanation: Output 5 is unlocked.

Info *The router issues the above response regardless of the previous state of the output (either it was locked or unlocked).*

7.5.10. Save preset to the specified memory location

Description: Save current crosspoint configuration (output states) to preset <id>.

Format	Example
Command {$<id>}	→ {$4}
Response (SPR<id²>)CrLf	← (SPR04)CrLf

Explanation: Current crosspoint state is saved to preset 4, including the mute state of the outputs.

Info: *Lock states are not saved. Lock state is assigned to the physical output of the router. Presets don't affect output locks.*

7.5.11. Load preset from the specified location

Description: Load preset <id>.

Format	Example
Command {%<id>}	→ {%4}
Response (LPR<id²>)CrLf	← (LPR04)CrLf

Explanation: Current crosspoint state is changed according to preset 4, including the mute state of the outputs.

Info: *Lock states are not loaded. Lock state is assigned to the physical output of the router. Presets don't affect output locks.*

PRELIMINARY VERSION!

7.5.12. Preview preset

Description: Preview preset <id> without loading.

Format		Example (MX8x8)
Command	{VP#<id>=?}	→ {VP#3=?}
Response	(VP#<id>=●<O1>●<O2>●<O3>●<O4>●<O5>●<O6>●<O7>●<O8>●<O9>●<O10>●<O11>●<O121>●<O13>●<O14>●<O15>●<O16>)CrLf	← (VP#3= 02 M02 M01 02 02 01 01 01 01 01 01 01 01 01 01 01)CrLf

Legend: Any <Ox> indexes can be a two digit number, or there can be a leading character showing the mute state for the corresponding output.

Explanation: Viewing connections for preset 3. Input 2 is connected to outputs 1, 2, 4 and 5. Input 1 is connected to all other outputs. Outputs 2 and 3 are muted. The shown input connections for these outputs are not active, but the last connection that was routed to that output before it was muted.

Index	Legend	Explanation
<Ox>	<in²>	<Ox> is connected to <in²>, <Ox> is not muted.
<Ox>	M<in²>	<Ox> is connected to <in²>, <Ox> is muted.

7.5.13. Renaming Presets / Inputs / Outputs

Description: Allows storing names for each preset / input / output. Any 16-byte long string is allowed. All characters are converted to uppercase! The router accepts <id> greater than the current I/O setup but treats it as modulo output. So if <id> = 17 on a 16x16 router, then it will be treated as 1. All router models have 32 presets memories.

Rename a preset

Format		Example
Command	{PNAME#<id>=<preset_name>}	→ {PNAME#1=first preset}
Response	(PNAME#<id>=<preset_name>)CrLf	← (PNAME#1=FIRST PRESET)CrLf

Explanation: Preset 1 was named as "first preset".

Rename an input

Format		Example
Command	{INAME#<id>=<input_name>}	→ {INAME#3=Media Player}
Response	(INAME#<id>=<input_name>)CrLf	← (INAME#3=MEDIA PLAYER)CrLf

Explanation: Input 3 was named as "media player".

PRELIMINARY VERSION!

Rename an output

Format		Example
Command	{ONAME#<id>=<output_name>}	→ {ONAME#2=Monitor_no2}
Response	(ONAME#<id>=<output_name>)CrLf	← (ONAME#2=MONITOR_NO2)CrLf

Explanation: Output 2 was named as “monitor_no2”.

7.5.14. Query names of Presets / Inputs / Outputs

Description: Each preset / input / output name can be read from the router.

Read a preset’s name

Format		Example
Command	{PNAME#<id>=?}	→ {PNAME#1=?}
Response	(PNAME#<id>=<preset_name>)CrLf	← (PNAME#1=FIRST PRESET)CrLf

Explanation: Name for preset 1 is “first preset”.

Read an input’s name

Format		Example
Command	{INAME#<id>=?}	→ {INAME#3=?}
Response	(INAME#<id>=<input_name>)CrLf	← (INAME#3=MEDIA PLAYER)CrLf

Explanation: Name for input 3 is “media player”.

Read an output’s name

Format		Example
Command	{ONAME#<id>=?}	→ {ONAME#2=?}
Response	(ONAME#<id>=<output_name>)CrLf	← (ONAME#2=MONITOR_NO2)CrLf

Explanation: Name for output 2 is “monitor_no2”.

7.5.15. Set default names of Presets / Inputs / Outputs

Description: Renames **all** preset / input / output names to the default: Preset 1..32 / Input 1..16 / Output 1..16 respectively.

Info: *The <id> field is not relevant here, only has to be a valid one. The command will affect ALL Presets / Inputs / Outputs disregarding the actual number that was in the command.*

Reload default preset names

Format		Example
Command	{PNAME#<id>=!}	→ {PNAME#2=!}
Response	(PNAME#<id>=Preset<id>)CrLf	← (PNAME#2=Preset 2)CrLf

PRELIMINARY VERSION!

Reload default input names

Format	Example
Command {INAME#<id>=!}	→ {INAME#4=!}
Response (INAME#<id>= Input<id>)CrLf	← (INAME#4=Input 4)CrLf

Reload default output names

Format	Example
Command {ONAME#<id>=!}	→ {ONAME#3=!}
Response (ONAME#<id>= Output<id>)CrLf	← (ONAME#3=Output 3)CrLf

7.5.16. Reload factory default output setup

Description: Reload factory default output drive currents.

Format	Example
Command {r00}	→ {r00}
Response (APWSE)CrLf	← (APWSE)CrLf

7.5.17. Query IP settings

Description: IP setup can be retrieved from the router with this command.

Format	Example
Command {IP_CONFIG=?}	→ {IP_CONFIG=?}
Response (IP_CONFIG=<id> ●<ip_address>●<port> ●<mask>●<gateway>)CrLf	← (IP_CONFIG=0 192.168.2.106 10001 255.0.0.0 192.168.2.1)CrLf

Legend:

Identifier	Description	Default value
<id>	0-fix IP, 7-DHCP	0
<ip_address>	IP address	192.168.254.254
<port>	IP port of the router	10001
<mask>	subnet mask	255.255.0.0
<gateway>	gateway address	0.0.0.0

Explanation: The router has a fix 192.168.2.106 IP address on the 255.0.0.0 subnet with a gateway on 192.168.2.1 and communicates over port no. 10001.

Info *If the matrix responds only zeros for this command, please unplug from power source, reconnect and try again.*

7.5.18. Reload factory default IP settings

Description: After issuing this command over serial connection the router will reload the factory default IP setup.

Format	Example
Command {IP_CONFIG=!}	→ {IP_CONFIG=!}
Response (Changing IP configuration…)CrLf (DONE!)CrLf or (FAILED!)CrLf	← (Changing IP configuration…)CrLf (DONE!)CrLf or (FAILED!)CrLf

PRELIMINARY VERSION!

Parameters after successful command execution:

Parameter	Value
IP address	192.168.254.254
port number	10001
Subnet mask	255.255.0.0
Gateway	0.0.0.0

Info *IP settings can NOT be changed with this protocol command via Ethernet connection, only via serial port. To change the IP settings via Ethernet, use the Matrix Controller software (section 4.6.1) or the built-in website (section 5.6). Default setting can be reloaded by the front panel buttons as well (section 7.3).*

7.5.19. Load DHCP IP settings (only IP address!)

Description: After issuing this command over serial connection the router will inquire IP address with DHCP.

Format	Example
Command {IP_CONFIG=D} Response (Changing IP configuration…)CrLf (DONE!)CrLf or (FAILED!)CrLf	→ {IP_CONFIG=D} ← (Changing IP configuration…)CrLf (DONE!)CrLf or (FAILED!)CrLf

Parameters after successful command execution:

Parameter	Value
IP address	Acquired with DHCP
port number	unchanged
Subnet mask	unchanged
Gateway	unchanged

Info *IP settings can NOT be changed with this protocol command via Ethernet connection, only via serial port. To change the IP settings via Ethernet, use the Matrix Controller software (section 4.6.1) or the built-in website (section 5.6). Default setting can be reloaded by the front panel buttons as well (section 7.3).*

PRELIMINARY VERSION!

7.6. Router Status commands

7.6.1. View product type

Description: The router responds its name.

Format	Example
Command {i} Response (<PRODUCT_TYPE>)CrLf	→ {i} ← (MX16x16DVI-Slim)CrLf

Legend:

<PRODUCT_TYPE>	inputs	outputs	interface
MX12x12DVI-Slim	12	12	single link
MX16x16DVI-Slim	16	16	single link

7.6.2. View serial number

Description: The router responds its 8-digit serial number.

Format	Example
Command {s} Response (<SERIAL_NUMBER>)CrLf	→ {s} ← (SN:09410135)CrLf

Info *Only the last 4 numbers are written onto the back of the router*

7.6.3. View Firmware version of the CPU

Description: View the CPU firmware revision. To view other controller's firmware version see *{FC} command*.

Format	Example
Command {f} Response (<FW_VERSION>)CrLf	→ {f} ← (FW:2.4.4)CrLf

7.6.4. View Installed I/O cards' hardware

Description: Shows the hardware name and revision of the installed cards.

Info *This router model is a compact type, so there are no separate input / output cards. Separate card slot descriptors are listed only because of compatibility issues.*

Format	Example
Command {is} Response (SL# 0 <MB_DESC>)CrLf (SL# 1 <OB_DESC>)CrLf (SL# 2 <OB_DESC>)CrLf (SL# 3 <OB_DESC>)CrLf (SL# 4 <OB_DESC>)CrLf (SL# 5 <IB_DESC>)CrLf (SL# 6 <IB_DESC>)CrLf (SL# 7 <IB_DESC>)CrLf (SL# 8 <IB_DESC>)CrLf	→ {is} ← (SL# 0 MX-16X16-DVI-SLIM SCH_2.1 PCB_2.1)CrLf ← (SL# 1 MX-16x16-DVI-OB SCH_2.1 PCB_2.1)CrLf ← (SL# 1 MX-16x16-DVI-OB SCH_2.1 PCB_2.1)CrLf ← Empty Slot ← Empty Slot ← (SL# 1 MX-16x16-DVI-IB SCH_2.1 PCB_2.1)CrLf ← (SL# 1 MX-16x16-DVI-IB SCH_2.1 PCB_2.1)CrLf ← Empty Slot ← Empty Slot

PRELIMINARY VERSION!

Explanation (MX16x16DVI-Slim router): The router reports as if it has two output ad two input cards.

7.6.5. View installed controllers' firmware

Description: Shows the firmware revisions of the installed controllers.

Format	Example
Command {fc} Response (<CARD_FIRMWARE>)CrLf	→ {fc} ← (CF MX-CP FW:1.0.4 @ 0x10)CrLf ← (CF MX-DVI-EDID FW:3.2.0 @ 0x50)CrLf

7.6.6. View current control protocol

Description: Shows the RS-232, TCP/IP control protocol.

Format	Example
Command {p_?} Response CURRENT●PROTOCOL●=●#<x>)CrLf	→ {p_?} ← (CURRENT PROTOCOL = #1)CrLf

Legend: <x> stands for the active protocol.

Explanation: Protocol 1 is active here.

7.6.7. Set current control protocol

Description: Sets the current RS-232, TCP/IP control protocol (Default is '1').

Format	Example
Command {p_x} Response (PROTOCOL●#<x>●SELECTED!)CrLf	→ {p_1} ← (PROTOCOL #1 SELECTED!)CrLf

Legend: <x> stands for the selected protocol.

Explanation: Protocol 1 is activated.

PRELIMINARY VERSION!

7.7. EDID router commands

The EDID router manipulates the EDID memory, which has memory locations that are assigned to specific input or output ports. Please see section 6 on page 49 about EDID memory structure.

7.7.1. Route EDID to the selected input (static)

Description: Copies EDID from location <loc> to input <in>. <loc> must be 1..100.

Format	Example
Command {<in>:<loc>}	→ {5:10}
Response (E_SW_OK)CrLf	← (E_SW_OK)CrLf
…delay…	…delay…
(E_S_C) CrLf	← (E_S_C) CrLf

Explanation: EDID from memory location 10 is copied to input 5.

Note: *The router sends (E_S_C) only if the new EDID is different from the earlier one.*

7.7.2. Route EDID to the selected input (dynamic)

Description: Copies EDID from location <loc> to input <in>. Location <loc> should be 101...116 (MX16x16DVI-Slim) or 101...112 (MX12x12DVI-Slim) as opposed to static routing where <loc> should be between 1..100.

Format	Example
Command {<in>:<loc>}	→ {4:102}
Response (E_SW_OK)CrLf	← (E_SW_OK)CrLf
…delay…	…delay…
(E_S_C) CrLf	← (E_S_C) CrLf

Info *Outputs 1..16 are mapped to logical addresses 101..116.*

Explanation: EDID from output 2 is copied to input 4.

After choosing dynamic EDID routing to one (or all inputs) the router will follow the EDID changes occurring on the output it was connected to. Every time a different EDID is recognized on the output, it is copied instantly to the input.

7.7.3. Route one EDID to all inputs

Description: Copies EDID from the selected location <loc> to all inputs. Location <loc> should be between 1..100 for static routing and between 101..116 for dynamic routing.

Format	Example
Command {A:<loc>}	→ {A:48}
Response (E_SW_OK)CrLf	← (E_SW_OK)CrLf
…delay…	…delay…
(E_S_C) CrLf	← (E_S_C) CrLf

Explanation: EDID from memory location 48 is copied to all inputs.

Info *This operation takes about 8 seconds.*

7.7.4. View EDID switch status on all inputs

Description: Indexes show the actual input and the number at the given index (<in1>..<inN>) shows which EDID is switched to that particular input where N represents the maximal input number of the given configuration.

PRELIMINARY VERSION!

Format		Example 1 (MX8x8)
Command	{VEDID}	→ {VEDID}
Response	(VEDID●<IN1>●<IN2>●<IN3>●<IN4>●<IN5>●<IN6>●<IN7> ●<IN8>●<IN9>●<IN10>●<IN11>●<IN12>●<IN13>●<IN14>●<IN15>●<IN16>)CrLf	← (VEDID 048 048 053 101 101 101 101 101 101 101 101 101 101 101 101)CrLf

Legend: Any <INx> indexes are **three digit** numbers showing the current EDID that is routed to the corresponding input. Respond length depends on input number of the router.

Explanation: Factory preset EDID from memory location 48 is emulated on inputs 1 and 2. User saved EDID from memory location 53 is emulated on input 3. EDID from output 1 is dynamically emulated on all other inputs.

7.7.5. Save EDID from output to memory location (Learn EDID)

Description: Learn EDID from the specified output <out> to the specified location <loc>. Memory locations 51..100 are available for saving learned EDIDs.

Format		Example
Command	{<out>><loc>}	→ {4>51}
Response	(E_SW_OK)CrLf	← (E_SW_OK)CrLf
	(E_S_C) CrLf	← (E_S_C) CrLf

Explanation: EDID from output 4 is saved to EDID memory location 51.

7.7.6. View EDID validity table

Description: Shows EDID validity table, which contains information about the EDID states.

Format		Example
Command	{wv}	→ {wv}
Response	(EV●<VALIDITY_TABLE>)CrLf	← (EV **11111111111111111111111111** ← **1111111111111111**1111111101111 0000000000000000000000000000 0000000000000000010*111111111 1111111000000000000000**11113 **1111111111000000000000000**)CrLf

Legend: Response length is 164 characters . Each number represents the EDID validity state for the corresponding memory location. The first 50 numbers (bold) are representing the factory preset EDIDs, the second 50 numbers are representing the User saved EDIDs. Next 16 numbers (italic) are showing the outputs' EDID state, and the last 16 numbers (bold and italic) are showing the emulated EDIDs on the inputs.

Value	Description
'0'	invalid EDID
'1'	valid EDID
'3'	changed EDID

If a changed EDID is queried by the *wh* command (see the next section), its value returns to '1'.

Explanation: There is one '3' in the table on the 137th position. This means that the emulated EDID on input 5 is changed since the last EDID query on that port.

PRELIMINARY VERSION!

7.7.7. View EDID header

Description: EDID_HEADER consists of 3 fields:

PNPID code The three letter abbreviation of the manufacturer

Preferred resolution The resolution and refresh rate stored in the preferred detailed timing block.

Name The name of display device stored in product descriptor.

Format	Example
Command {wh<loc>} Response (EH#<loc>● <EDID_HEADER>)CrLf	→ {wh104} ← (EH#104 NEC 1280x1024@60 LCD1970NXp)

Explanation: Shows the EDID from memory location 104.

7.7.8. Download EDID content from the router

Description: EDID hex bytes can be read directly. The router will issue the whole content of the EDID present on memory location <loc> (256 bytes).

Format	Example
Command {we<loc>} Response (EB#<loc>●<B1> ●<B2>●..●<B256>)CrLf	→ {we1>} ← (*EB#1 00 FF FF FF FF FF FF 00 32 F2 00 00 00 .. .. .. 00 92*) CrLf

Legend: <B1>..<B256> are space separated hex characters represented in ASCII format.

Explanation: Full EDID from memory location 1 is downloaded.

7.7.9. Upload EDID content to the router

Description: EDID hex bytes can be written directly to the user programmable memory locations (locations #51...#100).

Sequence:

Step 1. Prepare the router to accept EDID bytes to the specified location <loc> with command *{WL#<loc>}*

Step 2. Router responds that it is ready to accept EDID bytes with *(E_L_S)CrLf*

Step 3. Send 1 block of EDID (1 block consist of 8 bytes of hex data represented in ASCII format) with command *{WB#<num>●<B1>●<B2>●<B3>●<B4>●<B5>●<B6>●<B7>●<B8>}*

Step 4. The router acknowledges with response *(EL#<num>)*

Step 5. Repeat steps 3 and 4 to send the remaining 31 blocks of EDID (32 altogether)

Step 6. After the last acknowledge, the router indicates that the EDID status changed by sending *(E_S_C) CrLf*

PRELIMINARY VERSION!

Format		Example
Command	{WL#<loc>}	→ {WL#53}
Response	(E_L_S)CrLf	← (E_L_S) CrLf
Command	{WB#1●<B1>●<B2>●<B3>●<B4>●<B5>●<B6>●<B7>●<B8>}	→ {WB#1 00 FF FF FF FF FF FF 00}
Response	(EL#<num>)CrLf	← (EL#1) CrLf
Command	{WB#2●<B9>●<B10>●<B11>●<B12>●<B13>●<B14>●<B15>●<B16>}	→ {WB#2 38 A3 8E 66 01 01 01 01}
Response	(EL#<num>) CrLf	← (EL#2) CrLf
	⋮	⋮
Command	{WB#32●<B249>●<B250>●<B251>●<B252>●<B253>●<B254>●<B255>●<B256>}	→ {WB#32 36 59 42 0A 20 20 00 96}
Response	(EL#<num>) CrLf	← (EL#32) CrLf
Response	(E_S_C) CrLf	← (E_S_C) CrLf

Legend: <num> represents the sequential number of every 8 byte part of EDID. <num> is between 1 and 32. <B1>..<B256> are the bytes of EDID.

Explanation: Full EDID uploaded to memory location 53.

7.8. Router initiated commands

7.8.1. EDID status changed

Description: This is sent after all commands which changes the EDID (EDID copy, EDID switch), or after a new EDID source e.g. a new display device is connected to the router.

Format		Example
Command	*various*	→ {5:101}
Response	(E_S_C) CrLf	← (E_SW_OK)CrLf ← (E_S_C) CrLf

Explanation: Copy EDID from output 1 to input 5 (dynamic emulation). First response confirms the EDID routing command. (E_S_C) response is an automatic message that is sent because an EDID has changed.

Info *The router stores the last attached display device's EDID connected to the output. After disconnecting this device its EDID is still present at the router's memory, therefore no status change message is issued by the router if a display device having the same EDID is connected to that output. (The same display device is connected again, or another display device (same brand) from the same manufacturer)*

Info *To keep your application in sync with the router it is recommended to issue a show validity ({wv}) command after receiving an EDID status changed response, and read all location indicating '3' in the table, as the change of these EDID triggered the EDID status changed response.*

PRELIMINARY VERSION!

7.8.2. Error responses

Invalid input number

Description: Given input number exceeds the maximum number of inputs or equals zero.

Response	(ERR01)CrLf

Invalid output number

Description: Given output number exceeds the installed number of outputs or equals zero.

Response	(ERR02)CrLf

Invalid value

Description: Given value exceeds the maximum allowed value can be sent.

Response	(ERR03)CrLf

Invalid preset number

Description: Given preset number exceeds the maximum allowed preset number.

Response	(ERR04)CrLf

Info *The maximum preset number is limited to 32 for all routers.*

PRELIMINARY VERSION!

7.9. Commands – Quick summary

Control commands

Command description	See in chapter	Command
Switch one input to one output	7.5.1	{<in>@<out>}
Switch one input to all outputs	7.5.2	{<in>@O}
View connection on the specified output	7.5.3	{?<out>}
View connection on all outputs	7.5.4	{VC}
View mutes on all outputs	7.5.5	{VM}
Mute specified output	7.5.6	{#<out>}
Unmute specified output	7.5.7	{+<out>}
Lock specified output	7.5.8	{#><out>}
Unlock specified output	7.5.9	{+<<out>}
Save preset to the specified memory location	7.5.10	{$<id>}
Load preset from the specified location	7.5.11	{%<id>}
Preview preset	7.5.12	{VP#<id>=?}
Renaming Presets	7.5.13	{PNAME#<id>= <name>}
Renaming Inputs	7.5.13	{INAME#<id>= < name>}
Renaming Outputs	7.5.13	{ONAME#<id>= < name>}
Query names of Presets / Inputs / Outputs	7.5.14	{PNAME#<id>= ?}
Set default names of Presets / Inputs / Outputs	7.5.15	{PNAME#<id>= !}
Reload factory default output setup	7.5.16	{r00}
Query IP settings	7.5.17	{IP_CONFIG=?}
Reload factory default IP settings	7.5.18	{IP_CONFIG=!}
Load DHCP IP settings (only IP address!)	7.5.19	{IP_CONFIG=D}

Router Status commands

Command description	See in chapter	Command
View product type	7.6.1	{i}
View serial number	7.6.2	{s}
View Firmware version of the CPU	7.6.3	{f}
View Installed I/O cards' hardware	7.6.4	{is}
View installed controllers' firmware	7.6.5	{fc}
View current control protocol	7.6.6	{p_?}
Set current control protocol	7.6.7	{p_x}

PRELIMINARY VERSION!

EDID router commands

Command description	See in chapter	Command
Route EDID to the selected input (static)	7.7.1	{<in>:<loc>}
Route EDID to the selected input (dynamic)	7.7.2	{<in>:<loc>}
Route one EDID to all inputs	7.7.3	{A:<loc>}
View EDID switch status on all inputs	7.7.4	{VEDID}
Save EDID from output to memory location	7.7.5	{<out>><loc>}
View EDID validity table	7.7.6	{wv}
View EDID header	7.7.7	{wh<loc>}
Download EDID content from the router	7.7.8	{we<loc>}
Upload EDID content to the router	7.7.9	{WL#<loc>}

8. Firmware upgrade

Using Lightware bootloader application to upgrade router's firmware

The matrix router can only be upgraded via LAN, so connect the matrix router to the local subnet. Be sure that there is no other active connection with the router via Ethernet.

Step 1. Install the bootloader application with "Installer_LW_bootloader.exe"

Step 2. Download and save all the firmware files that you want to load. If you have a zipped archive, extract it.

Step 3. Run the application from

Start Menu → Programs → Lightware → LW_bootloader.



Figure 8-1. Bootloader main screen

PRELIMINARY VERSION!

Step 4. Click "*FIND*" Button!

If the bootloader finds one or more routers their IP addresses will be listed in the tree view window. On the tree view, device type and serial number is shown after the IP address.

Info *Note, that you must wait until all the devices on the network completely start up, before pressing FIND button.*



Step 5. Select the desired device

Double click on the IP address, then click "YES" to establish connection with the matrix router. It will take 10-15 secs to get all information from the router.



Warning *The bootloader application will hold the router in reset state when it establishes the connection. All connected DVI sources and monitors will act as if the router was powered down.*

PRELIMINARY VERSION!

Step 6. Review the firmware versions

After the connection is made, the device properties, and he installed hardware parts are displayed.



Select the one or more controllers that need firmware upgrade by clicking the checkbox next to it.

MX-DVI-CPU is the main processor's firmware, while MX-DVI-EDID is the firmware for the processor that handles EDID management. MX-CP1 is the firmware for the front panel.

Step 7. Browse for the new firmware(s)

Click the corresponding cell in the "Browse New Firmware" column. A dialog pops up, to confirm if you really want to modify the path. Now you can browse for the new firmware file to upload. After opening the new file, the new firmware field will contain the name of the firmware file.

Controller Type	Hardware Version	Bootloader Version	Firmware Version	Browse New Firmware
MX-DVI-CPU	HW:1.1	FW:1.1.1	FW:2.4.3	mx_dvi_cpu_v_2_4_4.hex
MX-DVI-EDID	HW:2.1	FW:1.0.2	FW:3.2.0	
MX-CP1	HW:2.0	FW:1.0.2	FW:1.0.4	
Web Server			FW:1.10.0	
Web Content			FW:1.2.6	

Step 8. Upgrade firmware(s)

Click "UPGRADE SELECTED FIRMWARES" button. A confirmation message appears. After clicking the "YES" button the selected controllers are being reprogrammed, with the firmware you selected. If you select a file that doesn't fit for the selected controller, you will get an information message about which file is wrong. If you selected a controller to upgrade, but you had not selected a file for it, then you will also get an information message about which file is missing.

Quick Bootload mode can be switched on or off any time. It makes the bootloader software faster by only checking the checksum of the controller. No data verification is done after writing if the checksum was correct.

Info: *The reprogramming can take between 3-8 minutes per controller.*

PRELIMINARY VERSION!

A progress bar will show in what stage the reprogramming is. An erasing process will take place first, and then the programming is done, so the progress bar runs up twice.

When the reprogramming is finished, a “Done!” message will appear in the bottom left corner. The application closes the connection, and the router restarts.

Step 9. Done!

If the upgrade was successful, the following window pops up:



Now you can close the application, or you can select another matrix router to upgrade. After closing the bootloader application, switch the upgraded devices off and then on. Now the router is ready to be used with the new firmware!

PRELIMINARY VERSION!

9. Troubleshooting

9.1. Serial connection problems

Check the cable and software settings

Check whether your null-modem cable is properly connected. In most cases there are more COM ports present in the operating system. Please verify the connection settings of your software. The router communicates with **9600** Baud, **8** data bit, **N**o parity, **1** stop bit.

Check the protocol

Check whether the proper protocol is selected (see section *7.1* about *Changing and viewing protocols* on page *50*). Select Protocol #1 in order to use the matrix with the controller software.

Check the router

Check whether the router is properly powered and whether CPU LIVE LED is blinking. Try performing a reset through the controller software, or unplug and reconnect the router's power cable.

9.2. TCP/IP connection problems

Check the LAN cable type

If you connect the router directly to your computer, you must use a cross-link cable. If the matrix is connected to an Ethernet hub, switch or router, you have to use a straight path LAN cable.

Check the IP settings

If you connect the router directly to your computer, you have to set the router's IP address manually, since in this case there is no DHCP server that could assign an address to the matrix.

If the IP address is set manually, check if there is an IP address conflict. If there is a DHCP server on the network, try to set the matrix to DHCP mode. See section *7.3* about *Ethernet port settings*.

Check whether your computer's firewall blocks the selected port.

Check alive connections

Only one connection is allowed simultaneously. Check whether there is another open connection (e.g. opened router web interface, running control software over Ethernet). Try restarting the router if you have no other option.

9.3. Picture is not displayed or distorted

Check the cables

Due to the high data rates, the cables must fit very well. DVI connectors have to be locked with screws, no tensions or breaches are allowed. If your source or display has more connectors then make sure that the proper interface is selected.

PRELIMINARY VERSION!

Although the router is equipped with DVI-I connectors, analog signals are not supported. You cannot use VGA cables with DVI-VGA adapter plugs.

Check the crosspoint matrix

Check the connection between the input and output port either on the front panel or from web or the control software. Check whether the output is muted or not.

Check EDID related problems

Maybe your display device is not capable of receiving the sent video format. Try emulating your display device's EDID to the source. You will find help on this process in section *4.4.1* about *EDID Router operation with control software* on page *35*, or in section *5.4* about *EDID Router operation with built-in website* on page *45*. If you get a picture now, you have an EDID related issue, please read section *1.5* about *Understanding EDID* on *11* for more details.

Check the source

Check whether your source is powered on and configured properly. The HDMI output can be turned off on most DVD players. If the source is a computer, then verify that the DVI output is selected and active. Try restarting your computer; if you get a picture during the booting process, you have to review the driver settings.

10. Version applicability

This User's Manual applies to the following versions of the mentioned software, firmware and hardware:

	version
Lightware Matrix Controller software	3.2.0
router CPU firmware (MX-DVI-CPU)	2.4.4
router EDID firmware	3.2.1
router Control Panel firmware (MX-CP1)	1.0.4
router Web Server	1.1.3
router Web Content	1.2.6
router Motherboard	PCB 2.1

PRELIMINARY VERSION!

11.Specifications

General

Power ..... 100-240 V AC 50/60 Hz 3 A
Compliance ..... CE, UL, FCC
EMI/EMC ..... EN 55103-1, EN 55103-2
Safety ..... EN 60065 Class I
Warranty ..... 3 years

Enclosure

Rack mountable ..... Yes, 4U high
Material ..... 1 mm aluminum alloy (AlMg3)
Dimensions ..... 482 mm W x 31,5 mm D x 176,5 mm H
Net Weight ..... 1850 gramms

Inputs

Connectors ..... 29-pole DVI-I digital only
Input cable equalization ..... Yes, +12dB fixed
EDID emulation ..... Yes, for each input connector

Signal

Data rate: ..... all between 25 Mbps and 2.25 Gbps / TMDS channel
Channels: ..... 1x TMDS Clock + 3x TMDS Colors
Resolutions: all between 640x480 and 1920x1200@60Hz or 2048x1080@60Hz
Color depth: ..... maximum 36 bits, 12 bit/color
Color format ..... RGB, YCbCr 4:4:4
HDTV resolutions: 720p, 1080i, 1080p
HDCP compliant: ..... No

PRELIMINARY VERSION!

Resolution	Vertical frequency (Hz)	Horizontal frequency (KHz)	Pixel Clock frequency (MHz)	Comment
640x480	60.00	31.47	25.18	**DOS VGA**
800x600	60.32	37.88	40	**VESA SVGA**
800x600	75.00	46.87	49.5	**VESA SVGA**
832x624	74.55	49.72	57.29	**MACINTOSH**
1280x720	60.00	45.00	74,25	**HDTV 720p**
1024x768	60.00	48.36	65	**VESA XGA**
1024x768	75.00	60.02	78.75	**VESA XGA**
1360x768	47.7	60.00		**WIDE-XGA**
1152x870	75.06	68.68	100	**MACINTOSH**
1280x1024	75.00	80.00	135.00	**VESA SXGA**
1400x1050	60.00	65.64	121.82	**SXGA+**
1920x1080	60.00	67.50	148.5	**HDTV 1080p**
2048x1080	60.00	67.50	157.3	**2K**
1600x1200	60.00	75.00	162	**VESA UXGA**
1920x1200	60.00	75.00	162	**VESA**

Table 11-1. DVI timing examples for some typical supported resolutions

Outputs

Connectors..... 29 pole DVI-I digital only

Output preemhasis..... Yes, +6dB fixed

Reclocking ..... No

+5V output current ..... 500 mA continuous each, with overcurrent protection

Control

Front Panel buttons..... Yes, 37 buttons

Serial Port ..... 9 pole D-SUB female RS-232 or RS-422

Command Execution delay RS-232 port ..... 47 miliseconds

Baud rate ..... 9600 Baud, 8 bit, 1stop bit, no parity

Ethernet port: ..... RJ45 female connector

Ethernet protocol..... TCP/IP, HTTP, TFTP, Telnet

IP address assignment .....fixed, DHCP, BOOTP, and AutoIP

PRELIMINARY VERSION!

11.1. Mechanical Drawings (router)

Front View


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
SOURCES
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
DESTINATIONS
visual engineering
LIGHTWARE
16x16 DVI MATRIX ROUTER
MX16x16DVI-Slim
178 mm
482 mm

Rear View



Top View



32 mm
housing only

39 mm
including buttons and connectors

PRELIMINARY VERSION!

Side View



11.2. Mechanical drawings (power supply)





PRELIMINARY VERSION!

12. Warranty

Lightware Visual Engineering warrants this product against defects in materials and workmanship for a period of three years from the date of purchase.

The customer shall pay shipping charges when unit is returned for repair. Lightware will cover shipping charges for return shipments to customers.

In case of defect please call your local representative, or Lightware at

Lightware Visual Engineering

1071. Budapest Peterdy str. 15, HUNGARY

Tel.: +36 1 889 6177

Fax: +36 1 342 9903

E-mail: support@lightware.hu

PRELIMINARY VERSION!

13.Quality Check Record

Model name	Serial number	Date of manufacture	Checked

Hardware

Card	HW
PSU	
Inputs	
Outputs	
SUBNET	
MAC ADDR	
IP ADDR	

Card	HW	FW
CPU		
EDID MGMT		
Control P		
Mother BRD		

Electrical check

GND/EARTH Safety	☐	Inputs	☐
+3.3V; +5V	☐	Outputs	☐
CPU Live	☐	RS-232	☐
Buttons	☐	LAN	☐

PRELIMINARY VERSION!

14.Revision history

Document	Release Date	Changes	Checked by
Rev. 1.0			
Rev. 0.8b	17-05-2010	first beta edition	Tamas Lehel
Rev. 0.1	21-04-2010	draft	-

PRELIMINARY VERSION!